

HP SureStore Optical Jukebox

160ex / 320ex / 400ex

Service Manual

Edition 1



HP Part No. C1160-90030

Printed in: Greeley, CO USA

© Copyright March 1998

Notice

This document contains information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company. The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this printed material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

© Copyright March 1998

Printing History

New editions of this manual incorporate all material updated since the previous edition. The manual printing date and part number indicate the current edition. The printing date changes when a new edition is printed. (Minor corrections and updates incorporated at reprint do not change this date.)

Part number C1160-90030

Edition 1

March 1998

Typographical Conventions

The following typographical conventions are used in this manual:

Emphasis: Denotes important information.

Keycap: Keys on the control panel.

Computer Output: Information displayed in the display window and menu items that you can select.

WARNING

Warnings call attention to a procedure or practice that could result in personal injury if not correctly performed. Do not proceed until you fully understand and meet the required conditions.

CAUTION

Cautions call attention to an operating procedure or practice that could damage the product if not correctly performed. Do not proceed until you understand and meet the required conditions.

NOTE

Notes provide information that aid in understanding the operation of the product.

In This Manual

This user's guide includes:

Chapter 1	Product Information
Chapter 2	Installation
Chapter 3	Operation and Configuration
Chapter 4	Troubleshooting and Diagnostics
Chapter 5	Removal and Replacement
Chapter 6	Theory of Operation
Appendix A	Safety and Regulatory Information
Index	

Contents

1. Product Information

Overview	1-2
Technical Specifications	1-3
Environmental Specifications	1-5
Clearance Requirements	1-8
Location Requirements	1-9
Responsibilities	1-10
Related Documents	1-11

2. Installation

Overview	2-2
Identifying Controls and Features	2-3
Connecting SCSI Cables to the Jukebox	2-6
Connecting the Jukebox as the Only Peripheral	2-7
Connecting the Jukebox With Other SCSI Peripherals	2-9
Connecting Power	2-10
Configuring Write Verify	2-11
Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode	2-12
Moving or Shipping the Jukebox	2-18
Moving the Jukebox a Short Distance	2-18
Shipping the Jukebox	2-18

3. Operation and Configuration

Overview	3-2
Operating the Control Panel	3-3

Contents

Using Selection Buttons	3-7
Understanding Display Window Messages	3-8
Top Level Menus	3-8
Second Level Menus	3-8
Loading a Disk	3-10
Ejecting a Disk	3-11
Entering the Administration Menu Password	3-12
Changing the Administration Menu Password	3-13
Setting the SCSI IDs	3-14
Setting the LUN Mode	3-14
Viewing the Current SCSI IDs	3-14
Changing the Current SCSI IDs	3-16
Setting an Operating Configuration	3-19
Retrieving Log History	3-22
4. Troubleshooting and Diagnostics	
Overview	4-2
Troubleshooting Using the Control Panel	4-3
Obtaining Troubleshooting Information	4-3
List of Possible Suspect FRUs	4-3
How Suspect FRUs Are Evaluated	4-4
Recovery Procedures for Operation/Installation Errors	4-5
Recovery Procedures for Specific Hardware Errors	4-12
Micro-Move Error Codes	4-23
Description of Micro-Moves	4-27
Running an Internal Test	4-39

Contents

5. Removal and Replacement

Overview	5-2
Protecting Yourself and the Product	5-3
Electrostatic Discharge (ESD) Precautions	5-3
Required Tools	5-3
Service Access	5-4
Removing the Right, Left, and Rear Access Panels	5-5
Removing the Left and Right Front Panels	5-6
Replacing a Power Supply	5-8
Replacing the Mailslot Assembly	5-9
Reassembly Notes	5-10
Replacing the Control Panel Assembly	5-11
Reassembly Notes	5-11
Replacing an Optical Drive — Jukebox Offline	5-12
Replacing an Optical Drive — Jukebox Online	5-16
Reassembly Notes	5-20
Replacing the Interposer PCA	5-21
Replacing the Picker	5-22
Removing/Replacing the Translate Frame (Including the Picker)	5-27
Reassembly Notes	5-31
Removing/Replacing the Vertical Encoder Strip	5-33
Replacing the Vertical Motion Motor	5-34
Replacing the Vertical Motor Gear Box	5-35
Reassembly Notes	5-37
Replacing the Controller PCA	5-39
Replacing the Interface PCA	5-41

Contents

Replacing the SCSI Cable	5-44
Checking the RFI Adjustments	5-45
Upgrading Firmware to the Current Revision Level	5-47
What is Needed	5-47
PC Tool hardware	5-47
Current Jukebox and Drive Firmware	5-48
Tools	5-48
Check the Firmware Revision Level	5-48
Download Firmware as Necessary	5-48
Replaceable Parts	5-51
6. Theory of Operation	
Overview	6-2
Jukebox Robotics	6-3
Movements	6-3
The Robotics Controller PCA	6-5
Interposer PCA	6-7
Configuration Module	6-9
Power Supplies	6-10
SCSI Interface PCA	6-11
Configuring This Jukebox on a SCSI Bus	6-14
Adding Devices to the Bus	6-15
Picker	6-19
Single-picker Mode	6-19
Dual-picker Mode	6-19
Optical Drive Mechanism	6-20
Controller	6-20

Contents

Central Processing Unit (CPU)	6-21
Gate Array	6-21
DSP (Digital Signal Processor)	6-21
Read / Write Channel Electronics	6-21
Loading Motor	6-21
Bias Magnet	6-22
Optical Head	6-22
Errors	6-22
Error Detection	6-24
A. Safety and Regulatory Information	
Overview of this Appendix	A-2
CDRH Regulations (USA Only)	A-3
United Kingdom Telecommunications Act 1984	A-4
Declaration of Conformity	A-5
Herstellerbescheinigung	A-6
English Translation of German Sound Emission Directive	A-6
Turvallisuusyhteenveto	A-7
Laserturvallisuus	A-7
Huolto	A-7
English Translation of Finland Regulatory Information	A-8
Japanese VCCI Statement	A-9

Index

Contents

Figures

Figure 1-1 . Clearance Requirements.	1-9
Figure 2-1 . Right Side.	2-3
Figure 2-2 . Left Side.	2-4
Figure 2-3 . Connecting the Jukebox as the Only Peripheral.	2-7
Figure 2-4 . Two or Four Drives, Basic SCSI Addressing	2-14
Figure 2-5 . Two or Four Drives, LUN Addressing, Controller/Drives Use Same ID	2-15
Figure 2-6 . Two or Four Drives, LUN Addressing, Controller/Drives Use Different IDs.	2-16
Figure 3-1 . The Jukebox Control Panel	3-4
Figure 3-2 . Jukebox Display Menu Tree	3-6
Figure 3-3 . Loading a Disk	3-10
Figure 4-1 . Suspect FRUs	4-4
Figure 5-1 . Mounting Screws on the Right, Left, and Rear Access Panels	5-5
Figure 5-2 . Control Panel Cables Disconnected When Removing the Right Front Panel	5-6
Figure 5-3 . Left and Right Front Panel Mounting Screws	5-7
Figure 5-4 . Cables and Mounting Screws on the Power Supplies	5-8
Figure 5-5 . Mailslot Assembly Mounting Screws	5-9
Figure 5-6 . Control Panel Assembly Mounting Screws	5-11
Figure 5-7 . Removing Drive Cables and Enclosure Mounting Screw	5-12
Figure 5-8 . Unmounting a Drive From An Enclosure	5-13
Figure 5-9 . Removing Cables From a Drive.	5-14
Figure 5-10 . Disk Eject Hole	5-15

Figures

Figure 5-11 . Online Drive Replacement LEDs, Communication Switches, and Drive Cables	5-16
Figure 5-12 . Disk Eject Hole	5-17
Figure 5-13 . Unmounting a Drive From an Enclosure.	5-18
Figure 5-14 . Disconnecting the Cables.	5-18
Figure 5-15 . Disconnecting Cables and Screws	5-21
Figure 5-16 . Picker Umbilical Cable	5-22
Figure 5-17 . Releasing and Stowing the Picker Translate Cable	5-23
Figure 5-18 . Holding the Translate Frame in Position	5-24
Figure 5-19 . Releasing the the Picker Capture Bracket	5-25
Figure 5-20 . Removing the Translate Frame Capture Bracket.	5-25
Figure 5-21 . Rotating the Picker Assembly Out of the Translate Frame	5-26
Figure 5-22 . Raising the Translate Frame and Holding the Frame in Position	5-27
Figure 5-23 . Releasing the Lower End of the Vertical Encoder Strip	5-28
Figure 5-24 . The Visual Locator Bracket.	5-29
Figure 5-25 . Disconnecting the Vertical Umbilical Cable From the Translate Frame	5-29
Figure 5-26 . Removing the Tensioners From the Translate Frame	5-30
Figure 5-27 . Rotating the Translate Frame Out of the Chassis	5-31
Figure 5-28 . Remounting the Tensioners on the Translate Frame	5-32
Figure 5-29 . Releasing the Ends of the Vertical Encoder Strip	5-33
Figure 5-30 . Cables and Mounting Screws on the Vertical Motion Motor	5-34
Figure 5-31 . Opening the Tensioners to Relieve Cable Tension	5-35
Figure 5-32 . Disconnecting the Rope Coupler	5-36

Figures

Figure 5-33 . Vertical Motor Gear Box Mounting Screw	5-37
Figure 5-34 . Positioning the Tensioner to Mount on the Translate Frame	5-38
Figure 5-35 . Placement of the Ropes in the Rope Coupler	5-38
Figure 5-36 . Removing the Controller PCA Cover	5-39
Figure 5-37 . Controller PCA Cables and Screws	5-40
Figure 5-38 . Removing the SCSI Interface Module	5-41
Figure 5-39 . Removing the SCSI Interface PCA	5-42
Figure 5-40 . Cables on the Interface PCA	5-43
Figure 5-41 . RFI Clamp on the GPIO and SCSI Cables	5-45
Figure 5-42 . Cable Clamps on the GPIO and SCSI Cables	5-46
Figure 5-43 . EMI Strip on the Right-Side Panel	5-46
Figure 5-44 . Exploded View (1 of 3)	5-55
Figure 5-45 . Exploded View (2 of 3)	5-56
Figure 5-46 . Exploded View (3 of 3)	5-57
Figure 5-47 . Power Cabling	5-58
Figure 5-48 . Rope and Pulley System	5-59
Figure 6-1 . SCSI Command Translations	6-3
Figure 6-2 . Robotic Controller PCA Block Diagram	6-6
Figure 6-3 . Interposer PCA Block Diagram	6-7
Figure 6-4 . Power Supplies and Poweron Sequence	6-10
Figure 6-5 . SCSI Interface PCA Block Diagram	6-11
Figure 6-6 . SCSI Interface PCA	6-12
Figure 6-7 . Single-ended and Differential Interfaces on This Jukebox	6-14

Figures

Figure 6-8 . Optical Drive Functional Diagram. 6-20

Tables

Table 1-1. Technical Specifications	1-3
Table 1-2. Environmental Specifications	1-5
Table 1-3. Power Requirements	1-7
Table 1-4. Reliability	1-8
Table 1-5. Product Certifications	1-8
Table 1-6. Reference Documents	1-11
Table 2-1. Maximum SCSI External Cable Lengths (Assuming no SCSI devices internal to the host computer)	2-6
Table 2-2. Default SCSI and LUN Settings	2-12
Table 2-3. LUN Mapping if “DRVs” SCSI ID is Changed to an ID Different Than the Jukebox (IDs used here are an example)	2-13
Table 2-4. Possible Additional SCSI Addresses Available	2-17
Table 3-1. Configuration Choices	3-20
Table 3-2. Information Logs	3-22
Table 4-1. Troubleshooting	4-5
Table 4-2. Hardware Errors Verification/Recovery	4-12
Table 4-3. Micro-Move Error Codes	4-23
Table 4-4. Micro-Move IDs and Expanded Descriptions	4-27
Table 4-5. Internal Tests	4-39
Table 5-1. Default Configuration Settings	5-50
Table 5-2. Exchange Parts	5-51
Table 5-3. Non-Exchange Assemblies	5-51

Tables

1

Product Information

Overview

This chapter gives information on the following topics:

- technical specifications
- environmental specifications
- replacing the control panel assembly
- other documents that apply to this product

Technical Specifications

Table 1-1

Technical Specifications

Characteristics	Description
Drive Characteristics	
Rotational speed (rpm)	<ul style="list-style-type: none"> • 3000 (5.2 Gb media) • 3600 (650 Mb, 1.2 Gb, 2.6 Gb media)
Average seek, typical (ms)	25.0
Average access time, typical (ms)	35
Write transfer rate - max sustained (Mb/s)	<ul style="list-style-type: none"> • 2.1 (5.2 Gb media) • 1.7 (2.6 Gb media) • 1.2 (1.2 Gb media)
Burst transfer rate -fast synchronous (Mb/s)	10
Burst transfer rate - synchronous (Mb/s)	5
Burst transfer rate - asynchronous (Mb/s)	3
Raw read/write error rate	Less than 2.0×10^{-4} errors / total bytes read
Buffer size (Mbytes)	1
Read buffering	Readaheads
Write buffering	Immediate reporting write re-ordering
Interface	Single-ended

Product Information
Technical Specifications

Characteristics	Description
Physical Characteristics	
Height (cm, inches)	111.8, 44
Width (cm, inches)	68.6, 27
Depth (cm, inches)	104.1, 41
Net weight (kg, lbs))	89.5, 197.3
Packaged weight kg, lbs)	119.3, 263

Environmental Specifications

Table 1-2

Environmental Specifications

Characteristics	Robotics	Drive	Media
Temperature (° C)			
Operating	10 to 40	5 to 45	10 to 60
Non-operating w/o disk	- 40 to 70	- 40 to 60	10 to 60
Max. Temperature gradient (° C /hr)	10	10	10
Transportation - <14 consecutive days			-40 to 60
Humidity, non-condensing (%)			
Relative operating	10 to 90	5 to 90	10 to 80
Non-operating w/o disk	5 to 95	5 to 95	10 to 90
Maximum wet bulb (° C)	29	29	29

Product Information
Environmental Specifications

Characteristics	Robotics	Drive	Media
Shock , non-operating (g/ms)			
End use, handling, half-sine	150 / 3	25 / 11	760 mm drop to 2mm vinyl-covered concrete
Transportation, trapezoidal (g/cm/s)	30 / 523	30 / 742	
Vibration, 5-500 Hz range (g rms)			
Operating, maximum acceleration (g rms)	0.21	0.3	>0.21
Non-operating random (g rms)	2	3	
Non-operating, swept-sine (g, 0-peak)	0.5	0.1	
Altitude (meters, feet)			
Operating	4,572 / 15,000		
Non-operating	15,240 / 50,000		
Acoustic emissions (dB - L noise power emission level)			
Operating (dB - L noise)	61.5		
Idle	47		

Characteristics	Robotics	Drive	Media
Particulates ($\mu\text{g}/\text{cm}^3$)			
	<200		
Electrostatic discharge (kV)			
Airgap (operating)	5 to 15	0 to 10	
Airgap (non-operating survival)	0 to 25	0 to 25	
Direct contact (operating)	0 to 4	0 to 4	
Cooling requirements (CFM)			
		15 (bidirectional through drive)	

Table 1-3

Power Requirements

Line voltage (Vac)	100 - 127, 200-240
Line frequency (Hz)	50 - 60
Power consumption, typical (Watts, BTU)	300, 1023
Power consumption (Watts, BTU)	340, 1,160
Current (amperes)	6 (120 V) 5 (240 V)

Product Information
Environmental Specifications

Table 1-4

Reliability

Mean swaps between failure (MSBF) - robotics	2,000,000
Mean swaps between failure (MSBF) -drive	750,000
Mean time between failure (MTBF) - robotics (power-on hours)	100,000
Mean time between failure (MTBF) - drive (power-on hours)	100,000
Mean time to repair (hours)	2
Preventive maintenance	none required* * for high-usage or zero downtime installations, see the Product Support Plan for special preventative maintenance schedules

Table 1-5


Product Certifications

Safety	EN 60950/IEC 950 UL 1950 listed or recognized
Electromagnetic emissions	FCC Class "A", CISPR 22, Class "A" Class "A" EN 55022/CISPR 22, Level "A"; VCCI Level 2
Laser	CDRH 21 CFR Chapter 1, Subpart J IEC 825

Clearance Requirements

A minimum 70-80 mm (3 in.) is required behind the rear panel to allow air to circulate.

Figure 1-1



- Figure A is usually in a row of peripheral cabinets.
 - Rear (w) requires 56 cm (18 in.) for cooling and service.
 - Front (z) requires 86 cm (34 in.) for operator access.
 - Sides (x) and (y) can be adjacent to other cabinets; the service panel (y) would be accessed by pulling the cabinet forward on its wheels.
- Figure B orientation represents free standing or against a wall.
 - Rear (1) requires 61 cm (24 in.) for service access.
 - Sides (2) and (3) require 30.5 cm (12 in.) for service, operator access, and cooling.
 - Front (4) requires 61 cm (24 in.) for service and operator access, plus additional space if the cabinet must be moved to access the rear panel (1).

Location Requirements

Position the jukebox away from sources of particulate contamination such as frequently-used doors and walkways, stacks of supplies that collect dust, printers, and smoke-filled rooms.

Product Information
Environmental Specifications

Responsibilities

Customer site preparation/verification and installation are the customer's or reseller's responsibility; HP will perform the site preparation/verification and/or installation on a time-and-materials basis.

Related Documents

Table 1-6**Reference Documents**

Document Name	Part Number	Edition
Installing and Administering Optical Jukeboxes, HP9000 Series 700 and 800	5966-9712	Ed. 1, 2/98
Optical Drive and Library SCSI-2 Command Reference	5966-9711	Ed. 8, 2/98
HP SureStore Optical 160ex, 320ex, and 400ex User Manual	C1160-90015	Ed. 1, 2/98

Product Information

Related Documents

2 **Installation**


Overview

This chapter gives information on the following topics:

- identifying controls and features
- connecting SCSI cables to the jukebox
- connecting the jukebox as the only peripheral
- connecting the jukebox with other peripherals
- connecting power
- configuring write verify
- default SCSI IDs in normal and LUN addressing
- moving and shipping the jukebox

Identifying Controls and Features

Figure 2-1 Right Side




- | | | |
|---|--------------------|---|
| 1 | Control panel | Used to manually control and monitor operation of the jukebox. A full description of the controls and indicators is in Chapter 3. |
| 2 | Mailslot | Used to load and eject optical disks. |
| 3 | Power switch | Used to power the jukebox on and off. |
| 4 | Right access panel | A panel that covers access to the optical drives and interposer PCA. |

Installation
Identifying Controls and Features

Figure 2-2

Left Side



- | | | |
|---|---------------------------------|---|
| 5 | Active bus indicator | Lit when the SCSI bus is active. There are indicators on the single-ended and differential interfaces. |
| 6 | SCSI interface selection switch | Used to select either the single-ended or differential SCSI interface. |
| 7 | SCSI ports | Used for attaching the SCSI cable from the jukebox to the host computer. Select either the single-ended or the differential pair of connectors (see item 5 in this list).

Both ports of a selected interface must be used. One port must have a SCSI cable connected, and the other must have either a SCSI terminator or other SCSI device connected to it. |
| 8 | Power receptacle | Connection for the power cord. |
| 9 | Left access panel | Covers the interface assembly (see components 5, 6, 7, and 8 above). |

Connecting SCSI Cables to the Jukebox

The following is general cabling information.

Interface types available	Single-ended or differential SCSI, selected by the interface selection switch on the top of the interface module (see “6” on Figure 2-2).
Number of hosts	<i>This jukebox may be used in high availability environments. High availability environments can be complex and are not described in this guide. The customer should consult with their high-availability vendor for installation and configuration.</i>

The maximum cable length you have available for connection to the host computer system or other devices depends on which interface *type* you select. The following table lists the maximum SCSI bus lengths available.

Table 2-1

Maximum SCSI External Cable Lengths (Assuming no SCSI devices internal to the host computer)

Interface Type	Maximum External Cable Length
Single-Ended SCSI (50-pin high-density connector)	3 meters (9.8 feet)
Differential SCSI (68-pin high-density connector)	25 meters (82.0 feet)

NOTE

Use SCSI cables with thumbscrew connectors. Clip type cables may be used if you first remove the mounted thumbscrew studs with a flat blade screwdriver. If the thumbscrew studs are not removed, interference between the cable and the studs may result. SCSI cables are listed in the replaceable parts list at the end of Chapter 5.


Connecting the Jukebox as the Only Peripheral

NOTE

This following configuration is the recommended configuration for this jukebox.

Figure 2-3

Connecting the Jukebox as the Only Peripheral



Refer to Figure 2-1 and Figure 2-2 for the locations of the following switches and connectors.

1. Ensure the power to the host computer is turned off.
2. Remove the left side access panel (side opposite the mailslot side), by lifting up on the bottom of the panel and then pulling it away.
3. Select either the single-ended or differential SCSI interface using the SCSI interface selection switch on the top of the interface assembly (under the left access cover (see “6” on Figure 2-2)).

Installation

Connecting the Jukebox as the Only Peripheral

4. Connect a cable between the host computer and one of the jukebox SCSI connectors of the selected interface type.

The SCSI cable may be connected to either of the two ports of an interface type.

NOTE

Plug a terminator into the *unused* port of the interface type used. Also, put a terminator on *one* of the port connectors of the unused interface type. .

The single-ended terminator has 50 pins, the differential terminator has 68 pins

NOTE

Go to “Connecting Power” and then to “Write Verify” to finish installation.

Connecting the Jukebox With Other SCSI Peripherals

NOTE

Operating this jukebox with other peripherals on the same bus is supported, but not recommended.

In most circumstances, the recommended configuration for this jukebox is as the only device on a SCSI bus. However, the customer may be using the jukebox in a way that connecting other devices to the same bus will not result in a loss of performance.

It is possible to connect this jukebox on a bus with additional peripherals in many different ways depending on the model:

- a 2- or 4-drive jukebox using basic SCSI addressing or
- a 2- or 4-drive jukebox using *logical unit numbering* (LUN) addressing

Some issues that the customer should considered when evaluating whether other devices may be connected on the same bus as this jukebox include the following:

- How will the jukebox be used: archiving, backup, near-line storage? What performance must be maintained?
- How will the other device under consideration be used? How much demand will the additional device place on the bus?
- Will “wide” and “narrow” devices have to be mixed?
- Are there devices on the internal part of the SCSI bus?
- Will a single-ended or differential interface be used?

NOTE

The section provides a brief overview of SCSI and the issues that must be considered when placing other peripherals on the same bus with this jukebox. More extensive information and frequently asked questions are at the web site: www.hp.com/isgsupport/optical/index.html

Connecting Power

1. Ensure the power switch on the jukebox is off (see #3 Figure 2-1).
2. Plug the socket end of the power cord into the power port on the bottom of the interface enclosure (see “8” on Figure 2-2).

NOTE

Use the power cord shipped with the jukebox.

3. Plug the other end of the power cord into a power outlet.
4. After the jukebox is moved to its operating location, lower the leveler feet and tighten the 1/2-inch nut on each foot.
5. Turn the power on.

TESTING and NOT READY alternately display. Once the power on test completes (approximately 1.5 minutes), READY displays.

NOTE

If DEVICE FAILED displays. See “Troubleshooting” in Chapter 4 for troubleshooting procedures.

NOTE

Go to “Configuring Write Verify” on the next page to continue the installation.

Configuring Write Verify

The write verify configuration ensures that data is written reliably to an optical disk. The jukebox ships with write verify enabled. Many software applications also default to this method of writing.

Writing data on a magneto-optical disk requires two passes. The first pass erases the data in the sector to which data will be written. The second pass writes new data to that sector.

When write verify is on, an additional pass is made over the sector to verify that all data is written correctly to the sector. The recommended setting is on (write verify enabled). Note that when write verify is enabled, write operations take more time.

To set write verify to off, refer to “Configuring Operating Configurations” in Chapter 3.

NOTE

The last step in the installation process is to set the SCSI IDs for the jukebox and drives. Setting SCSI IDs is explained in “Setting the SCSI IDs” in Chapter 3.

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Table 2-2

Default SCSI and LUN Settings

	LUN Mode OFF		LUN Mode ON	
	ID	LUN	ID	LUN
JKBX ID	6	0	6	0
DRV 1 ID	5	0	6	1
DRV 2 ID	4	0	6	2
DRV 3 ID*	3*	0*	6*	3*
DRV 4 ID*	2*	0*	6*	4*

* 320ex models only

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Table 2-3 **LUN Mapping if “DRVs” SCSI ID is Changed to an ID Different Than the Jukebox (IDs used here are an example)**

	LUN Mode ON	
	ID	LUN
JKBX ID	5	0
DRV 1 ID	6	0
DRV 2 ID	6	1
DRV 3 ID*	6*	2*
DRV 4 ID*	6*	3*


* 320ex models only

Installation

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Figure 2-4

Two or Four Drives, Basic SCSI Addressing



Displays on the Control Panel

Under CHOOSE LUN MODE * menu >> LUN MODE OFF

Under SCSI IDs * menu

>> JXBX ID 6 LUN 0

DRV 1 ID 5 LUN 0

DRV 2 ID 4 LUN 0


DRV 3 ID 3 LUN 0 (if installed)

DRV 4 ID 2 LUN 0 (if installed)

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Figure 2-5

Two or Four Drives, LUN Addressing, Controller/Drives Use Same ID



Displays on the Control Panel

Under CHOOSE LUN MODE * menu >> LUN MODE ON

Under SCSI IDs * menu

>> JYBX ID 6 LUN 0

DRV 1 ID 6 LUN 1

DRV 2 ID 6 LUN 2

DRV 3 ID 6 LUN 3 (if installed)


DRV 4 ID 6 LUN 4 (if installed)

Installation

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Figure 2-6

Two or Four Drives, LUN Addressing, Controller/Drives Use Different IDs



Displays on the Control Panel

Under CHOOSE LUN MODE * menu >> LUN MODE ON

Under SCSI IDs * menu

>> JXBX ID 6 LUN 0

DRV 1 ID 5 LUN 0

DRV 2 ID 5 LUN 1

DRV 3 ID 5 LUN 2 (if installed)

DRV 4 ID 5 LUN 3 (if installed)

Default SCSI IDs in the Jukebox When Using Basic SCSI Addressing and When Using LUN Mode

Table 2-4

Possible Additional SCSI Addresses Available

No. of Drives	LUN mode OFF (Basic SCSI Addressing)	LUN Mode ON - (drives & jukebox controller use the same ID)*	LUN Mode ON - (drives & jukebox controller use different IDs)
2	4 IDs are available for connecting other devices.	6 IDs are available for connecting other devices.	5 IDs are available for connecting other devices.
4	2 IDs are available for connecting other devices.		

* Not recommended. This configuration may cause a “negotiated” slower rate of data transfer.

Moving or Shipping the Jukebox

Moving the Jukebox a Short Distance

1. If removing the disks from the jukebox, follow the jukebox application software instructions for unmounting, ejecting, and labeling disks to ensure that the jukebox can be brought online again easily.

Ensure that there are no disks in the drives.

If manually ejecting disks, refer to “Ejecting Disks ” in Chapter 3.

CAUTION

Moving the jukebox with a disk in a drive could damage the drive mechanism.

CAUTION

Turning off the jukebox in the next step could cause data loss if not done correctly.

Do not turn off power to the jukebox until you are sure the SCSI bus is *inactive*. Removing power from a SCSI peripheral when the bus is active can result in data loss and/or indeterminate bus states. Check the host system manuals for information about checking the SCSI bus status. If the computer is connected to a LAN, be sure to check with the system administrator before turning off power to the jukebox.

2. Switch jukebox power off.
3. Remove the right side access panel.
4. Remove the power cord and the SCSI cable connections.
5. Loosen the 1/2-inch nut securing the leveler feet and screw the feet up to raise them away from the floor.
6. Carefully move the jukebox to its new destination.
7. Set up the jukebox at its new location.
8. Lower the leveler feet and tighten the 1/2-inch nut on each foot.
9. Bring the jukebox online according to the customer’s system requirements.

Shipping the Jukebox

1. Follow the jukebox application software instructions for unmounting and ejecting disks.

Ensure that there are no disks in the drives.

If manually ejecting disks, refer to “Ejecting Disks” in Chapter 3.

CAUTION

Moving the jukebox with a disk in a drive could damage the drive mechanism.

Failure to remove all disks from the storage slots in the jukebox could result in damage to the jukebox.

2. Follow the jukebox application’s instructions for labeling the disks according to what the customer will be doing with the disks (example: archiving, moving them to another jukebox, etc.).

CAUTION

Turning off the jukebox in the next step could cause data loss if not done correctly.

Do not turn off power to the jukebox until you are sure the SCSI bus is *inactive*. Removing power from a SCSI peripheral when the bus is active can result in data loss and/or indeterminate bus states. Check the host system manuals for information about checking the SCSI bus status.

3. Switch jukebox power off.
4. Remove the right side access panel.
5. Remove the power cord and the SCSI cable connections.
6. Loosen the 1/2-inch nut securing each leveler foot and screw the four feet up to raise them away from the floor.
7. Repackage the jukebox in the same way it was received.

Installation

Moving or Shipping the Jukebox

Overview

This chapter gives information in the following topics:

- operating the control panel
- using the selection buttons
- interpreting messages in the display window
- loading optical disks into the jukebox
- ejecting optical disks from the jukebox
- entering the administration menu password
- administration menu password
- setting SCSI IDs or logical unit numbers (LUNs)
- setting configurations
- retrieving log history
- running tests

Operating the Control Panel


The control panel enables manual control of all jukebox operations using four buttons and an LED display.

The SCSI IDs of the jukebox and its optical drives can be set and changed, disks may be loaded and ejected, configurations can be monitored and changed, performance information can be viewed, internal tests can be run, and the jukebox can be secured from unauthorized use.

Operation and Configuration
Operating the Control Panel

Figure 3-1

The Jukebox Control Panel



The numbers below refer to the numbers in Figure 3-1 on the previous page.

- | | | |
|---|----------------------|---|
| 1 | Swivel feature | The control panel assembly may be rotated to face the display (#3 below) toward the front or right side of the jukebox. The front has the vertical window, the right side has the mailslot. |
| 2 | Activity light | Lit differently to indicate the following: <ul style="list-style-type: none">• Steady Green - power is on• Flashing Green - an optical drive is being accessed• Amber - a fault occurred |
| 3 | 16-character display | Displays information about the current operation. |
| 4 | Selection buttons | Pressed to perform the following operations:
CANCEL cancels the current operation or choice
PREV scrolls the display choice backward by one
NEXT scrolls the display choice forward by one
ENTER selects the displayed choice |
| 5 | Power switch | Used to power the jukebox on and off. |
| 6 | Mailslot | Used to load and eject optical disks |


NOTE

Figure 3-2 shows the jukebox menus available using the control panel selection buttons.

Operation and Configuration

Operating the Control Panel

Figure 3-2 Jukebox Display Menu Tree



Using Selection Buttons

Use the **LOAD**, **EJECT**, **NEXT**, **PREV**, **CANCEL**, and **ENTER** buttons to select tasks. When you push these buttons, the message in the display window changes. See the next section for a list of messages.

Each time you push the **NEXT** or **PREV** button, a task choice appears.

- An “*” in the message indicates there is a menu beneath that choice, which you can access by pressing the **ENTER** key.
- Additional choices can be displayed by pressing the **NEXT** or **PREV** key.
- The display scrolls faster by holding the **NEXT** or **PREV** key.

NOTE

You can get back to **READY** at any time by pressing **CANCEL**. (You may have to press **CANCEL** more than once in some cases.)

Understanding Display Window Messages

The display window shows the operations you may select. Instructions for selecting or changing choices follows the explanation of the messages.

Top Level Menus

READY	The jukebox is ready for operation.
ADMIN *	Select to access second-level choices. A security code is required to access these choices.

NOTE

A * indicates that there are multiple selections available for that choice currently displayed. When a choice is flashing, press **ENTER** to select it or **PREV** or **NEXT** to display other choices.

Second Level Menus

A security code must be entered to access these functions. See “Entering the Administration Menu Password” later in this chapter. A default password of 000 000 000 is set at the factory. The customer will probably change this default code to a private code to prevent unauthorized access to the jukebox. See “Changing the Administration Menu Password” in this chapter.

TEST *	Select to run internal tests.
INFO *	Select to retrieve performance information stored in the jukebox logs.
CONFIG *	Select to customize the way the jukebox functions.
SCSI IDs *	Select to view and/or change the SCSI IDs and logical unit numbers (LUNs).
ONLINE REPAIR *	Select to view and change drive settings for online drive replacement.

NOTE

When a menu selection flashes, press **ENTER** to choose that selection, or press **PREV** or **NEXT** to display other choices that available in that part of the menu.


You can display the selections listed in boxes below the *shaded* choices in Figure 3-2 by pressing **ENTER** when one of the shaded choices displays. Press **PREV** or **NEXT** to scroll through the list. To perform the displayed operation, press **ENTER**.

Loading a Disk

Start with READY or LOAD in the display.

Figure 3-3

Loading a Disk



1. Insert a disk into the mailslot with Side A of the disk facing up. The shutter end of the disk goes in the mailslot first.

When the disk is inserted, it is automatically pulled into the mailslot. An incorrectly inserted disk is rejected, **CART IN WRONG** displays briefly, and then **LOAD SLOT #** displays. (“#” is flashing and is the number of the first available storage slot in the jukebox.)

2. If you want to select the storage slot number that shows in the display, press **LOAD** or **ENTER**. If you want to choose a different storage slot, press **NEXT** or **PREV** until the desired slot number displays, and then press **ENTER**.
3. **LOADING** displays as the jukebox moves the disk to the slot. After the disk is loaded into the selected storage slot, the display returns to **LOAD ***. YLoad additional disks by inserting the disks into the mailslot and repeating steps 1-3 until you are finished.
4. Press **CANCEL** to return to the **READY** state.

Ejecting a Disk

Start with READY in the display.

1. Press **NEXT** until **EJECT *** displays and then press **ENTER**.
2. **EJECT SLOT #** displays. (“#” is flashing and the number of the first storage slot in the jukebox that contains an optical disk.)
3. If you want to select the storage slot number that shows in the display, press **EJECT** or **ENTER**. If you want to choose a different storage slot, press **NEXT** or **PREV** until the desired slot number displays and then press **ENTER**.

EJECTING displays as the jukebox moves the disk to the mailslot. When the disk is in the mailslot, the display returns to **EJECT SLOT #**.

4. Remove the disk from the mailslot.

You may now eject additional disks by pressing **ENTER** and then following steps 2 through 4 until you are finished ejecting disks. When the last disk is ejected, **EMPTY** displays briefly before returning to **EJECT ***.

5. Press **CANCEL** to return to the **READY** state.

Entering the Administration Menu Password

READY > ADMIN * > PSWD 000 000 000

A numeric password is required to access choices in the ADMIN * menu (see Figure 3-2). A three-part password of 000-000-000 was set at the factory. The customer may have set a new password. Coordinate with the system administrator, if necessary, to access choices in the ADMIN * menu.

The following steps describe how to enter the password. For your reference, a description of changing the password is in “Changing the Administration Menu Password” on page 3-13. Changing the password is an operation normally used only by the customer.

Start with READY in the display.

1. Press **NEXT** until **ADMIN *** displays.
2. Press **ENTER**. **PSWD 000 000 000** displays and the first set of three zeros flashes.

NOTE

If the default password, 000 000 000, is still in effect, accept this password by pressing **ENTER** three times (once for each set of three zeros). **TEST *** displays which indicates you are in the menu tree below ADMIN *.

Entering a private password is described in steps 3 to 5 below. You may have to ask the system administrator enter this password.

3. Press **NEXT** or **PREV** until the first number of the password displays. Press **ENTER**. The middle set of three zeros flashes.
4. Press **NEXT** or **PREV** until the second number of the password displays. Press **ENTER**. The third set of three zeros flashes.
5. Press **NEXT** or **PREV** until the third number of the password displays. Press **ENTER**. **TEST *** displays.

To access menu choices under the ADMIN * menu press **NEXT** or **PREV** or until the desired choice displays, and then press **ENTER**.

Changing the Administration Menu Password

READY > ADMIN * > PSWD 000 000 000 >CONFIG *

NOTE

The following procedure is normally not used by service.

1. Follow the steps on the previous page to enter the customer's password (or the default, factory-set password 000 000 000).
2. TEST * displays. Press **NEXT** until CONFIG * displays, and then press **ENTER**.
3. Press **NEXT** or **PREV** or until NEW PASSWORD displays and then press **ENTER**.
4. NEW 000 000 000 displays and the first set of three zeros flashes. Press **NEXT** or **PREV** until the new number you want to assign to the first part of the password displays and then press **ENTER**. The second set of three zeros flashes.
5. Press **NEXT** or **PREV** until the new number you want to assign to the second part of the password displays and then press **ENTER**. The third set of three zeros flashes.
6. Press **NEXT** or **PREV** until the new number you want to assign to the third part of the password displays and then press **ENTER**.
7. PASSWORD CHANGED displays. Press **CANCEL** three times to return to READY

CAUTION

Turning off the jukebox in the next step could cause data loss if not done correctly.

Do not turn off power to the jukebox until you are sure the SCSI bus is *inactive*. Removing power from a SCSI device when the bus is active can result in data loss and/or indeterminate bus states. Check the host system manuals for information about checking the SCSI bus status.

8. Turn the jukebox OFF, then ON to save the password to the jukebox flash ROM.

Setting the SCSI IDs

Tables showing default SCSI IDs for basic SCSI addressing and LUN addressing are in Chapter 2, “Installation.”

Setting the LUN Mode

READY > ADMIN * > SCSI ID'S * > CHOOSE LUN MODE *

NOTE

LUN mode can only be configured if the host system and jukebox application software support the use of LUNs.

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays and then press **ENTER**.
2. Enter the administration password.
You may have to coordinate with the system administrator to enter the password.
3. Press **NEXT** until SCSI ID'S displays, and then press **ENTER**.
4. VIEW ID'S displays. Press **NEXT** until CHOOSE LUN MODE * displays and then press **ENTER**. LUN MODE ON or LUN MODE OFF displays and ON or OFF is blinking.
5. Press **NEXT** to change the setting and then press **ENTER**. WAIT FOR UPDATE and then TURNED OFF or TURNED ON display briefly. Then SCSI ID'S displays.

You may now view the SCSI ID and LUN numbers using VIEW ID'S, or set a new SCSI ID number using SET ID'S.

Viewing the Current SCSI IDs

READY > ADMIN * > SCSI ID'S * > VIEW ID'S * >

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays, and then press **ENTER**.
2. Enter the administration password.

You may have to coordinate with the system administrator to enter the password.

3. Press **NEXT** until SCSI ID'S displays, and then press **ENTER**.
4. VIEW ID'S displays. Press **ENTER**.
5. JKBX ID # LUN # or DRV # ID # LUN # displays. (JKBX ID # stands for the current ID of the jukebox controller, DRV # ID # is the current ID setting of the displayed drive number, and "LUN #" is the current logical unit number.)

Press **NEXT** or **PREV** to scroll through the current SCSI IDs and LUNs.

NOTE

Tables showing default SCSI IDs for basic SCSI addressing and LUN addressing are in Chapter 2, "Installation."

6. Press **CANCEL** twice to exit VIEW ID'S.

Changing the Current SCSI IDs

READY > ADMIN * > SCSI ID'S * > SET ID'S *

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays, and then press **ENTER**.
2. Enter the administration password.

You may have to coordinate with the system administrator to enter the password.

3. Press **NEXT** until SCSI ID'S displays, and then press **ENTER**.
4. VIEW ID'S displays. Press **NEXT** until SET ID'S displays and then press **ENTER**.

If the jukebox configuration uses basic SCSI addressing (LUN mode OFF):

JKBX ID # LUN # or DRV # ID # LUN # displays. (JKBX ID # stands for the current ID of the jukebox controller, LUN # is the current logical unit number, and DRV # ID # is the current ID setting for the displayed drive number.) When using basic SCSI addressing, the LUN # is always 0.

If the jukebox configuration uses LUN addressing (LUN mode ON):

JKBX ID # or DRV# # ID displays. (“#” is the current ID for the jukebox controller and drives when LUN mode is ON.)

5. Press **NEXT** until the setting you wish to change displays, and then press **ENTER**. The # (current ID) begins flashing.

NOTE

This jukebox, by default, assigns ID 6 to the jukebox controller. When in LUN mode, the jukebox controller ID uses LUN 0 for itself and assigns the drives on Bus 1 to LUNs 1 to 2 or LUNs 1 to 4 depending on whether there are two or four drives. In the default configuration, two types of devices, controller and drives, are assigned to ID 6.

Some host computer systems do not allow assigning different device types to the same ID. If the host computer system does not support multiple device types at the same ID and the customer will use LUN mode, select *different* IDs for the jukebox controller (JKBX ID #) and the drives (DRV #).

Tables near the end of Chapter 2 show jukebox default settings and an example of setting the jukebox controller and drives to different IDs, one digit apart.

Placing a device ID between the jukebox controller ID and the ID for the drives can cause bus management problems. For this reason, the jukebox *will not accept* IDs for the jukebox controller and drives that are more than one digit apart. An attempt to set IDs more than one digit apart will cause a CONFLICT message.

6. Press **NEXT** or **PREV** until the desired ID displays and then press **ENTER**.

If the jukebox is set to LUN MODE ON, go to Step 8. Only one ID can be changed and the ID automatically updates when you press **ENTER**.

7. (If using basic SCSI addressing - LUN mode OFF) Press **NEXT** until UPDATE displays, and then press **ENTER**.

8. UPDATE or WAIT FOR UPDATE and then ID'S SAVED displays briefly.

- If the new settings do not conflict with other SCSI IDs on the bus, SCSI ID'S displays.
- If the new settings conflict with other IDs on the SCSI bus, CONFLICT-ABORTED displays briefly and then VIEW ID'S displays. Any changes entered are lost, and you must repeat steps 3 through 6 to set a new ID.

NOTE

When in LUN mode:

If the new ID chosen results in the IDs for the jukebox controller and the drives being more than one digit apart, the jukebox displays CONFLICT and rejects the ID.

9. Press **CANCEL** until READY displays.

CAUTION

Turning off the jukebox in the next step could cause data loss if not done correctly.

Setting the SCSI IDs

Do not turn off power to the jukebox until you are sure the SCSI bus is *inactive*.
Check the host system manuals for information about checking the SCSI bus status.

10. Turn the jukebox OFF, then ON to save the IDs to the jukebox flash ROM.

Setting an Operating Configuration

READY > ADMIN * > CONFIG *

Configurations customize the way the jukebox operates.

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays.
2. Enter the administration password.
You may have to coordinate with the system administrator to enter the password.
3. TEST * displays. Press **NEXT** until CONFIG * displays, and then press **ENTER**.
4. Press **NEXT** or **PREV** until the name of the configuration you want to set displays and then press **ENTER**. (Configurations are described on the following pages.)

If the configuration has multiple settings, the current setting flashes. Otherwise, the configuration is set and a confirmation message displays.

5. If the current configuration setting is flashing, press **NEXT** or **PREV** until the desired setting displays, and then press **ENTER**. OPTION SAVED displays and then the configuration's name and setting displays.
6. Press **CANCEL** to return to READY.

CAUTION

Turning off the jukebox in the next step could cause data loss if not done correctly.

Do not turn off power to the jukebox until you are sure the SCSI bus is *inactive*. Removing power from a SCSI device when the bus is active can result in data loss and/or indeterminate bus states. Check the host system manuals for information about checking the SCSI bus status.

7. Turn the jukebox OFF, then ON to save the configuration to the jukebox flash ROM.

Configurations are described in the following table.

Operation and Configuration
Setting an Operating Configuration

Table 3-1

Configuration Choices

Configuration Name	Description
RECOVERY ON/OFF	Toggles between ON and OFF. If set to ON, the jukebox attempts to recover from errors. If set to OFF, the jukebox immediately stops moving if an error condition occurs. The default configuration is RECOVERY ON, and recovery should remain ON under normal conditions.
RESTORE DEFAULTS	Sets all jukebox configurations to default settings.
CLEAR ODOMETERS	Sets all jukebox odometers to zero.
DUAL PICKER ON/OFF	Toggles between ON and OFF. If set to ON, the jukebox runs with dual picker addressing ON. If set to OFF, the jukebox runs with dual picker addressing OFF. The default setting is DUAL PICKER ON and this mode should remain ON under normal conditions. Single and dual-picker addressing is described in Chapter 6 on page 6-18.
STARWARS ON/OFF	Toggles between ON and OFF. If set to ON, the vertical sensors are enabled. If set to OFF, the vertical sensors are disabled. The default configuration is ON and should remain ON during normal operation.
NEW PASSWORD	Allows changing the numerical password required to access the menu choices under the ADMIN * menu on the jukebox control panel. Menu choices include configurations, tests, and information logs. To change the security code, see “Changing the Administration Menu Password” on page 3-13.
SCSI LOG ON/OFF	Toggles between ON and OFF. If set to ON, SCSI states are tracked and saved to a log. If set to OFF, SCSI states are not tracked or saved. The default configuration is OFF and should remain OFF during normal operation.

Configuration Name	Description
SECURE ON/OFF	Toggles between ON and OFF. If set to ON, loading and ejecting disks is disabled. If set to OFF, loading and ejecting disks is enabled. The default configuration is ON.
SECURE MAIL OUT/IN	Determines the orientation of the mailslot when the SECURE configuration is set to ON. Toggles between OUT and IN. If set to OUT, the mailslot remains in its normal configuration. If set to IN, the mailslot rotates inwards, making the mailslot inaccessible. The default configuration is OUT??
POWER SECURE ON/OFF	Toggles between ON and OFF. If set to ON, the selection of the SECURE MS configuration is retained through power cycling (or power outage). If set to OFF, the jukebox returns to the default setting of this configuration after a power cycling. The default setting of this configuration is OFF).
REP RECOVERED ON/OFF	Toggles between ON and OFF. If set to ON, recovered errors are reported. If set to OFF, recovered errors are not reported. Default setting is ON.
CONF40 ON/OFF	Toggles between ON and OFF. If set to ON, Select Inquiry Mode ON selects standard inquiry mode. If set to OFF, Select Inquiry Mode ON selects downloadable inquiry mode. Default is OFF.
WRITE VERIFY ON/OFF	Toggles between ON and OFF. If set to ON, write verify is forced. When set to OFF, the drives may write verify or not, depending on how they are manually configured or how they are configured by the jukebox application software. The default configuration is ON.

Retrieving Log History

READY > ADMIN * > INFO *

Information stored in the jukebox operating logs is displayed by using the INFO * menu.

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays.
2. Enter the administration password.
You may have to coordinate with the system administrator to enter the password.
3. TEST * displays. Press **NEXT** until INFO * displays, and then press **ENTER**.
4. Press **NEXT** until the name of the log you wish to access displays and then press **ENTER**. (A “*” indicates that there are more selections beneath the displayed choice.)
5. After you are finished viewing log information, press **CANCEL** to return to READY.

Information logs are described in the following table.

Table 3-2

Information Logs

Log Name	Description
REVISION	Jukebox firmware version number.
JUKEBOX *	Press ENTER to select the information described in the next five rows.
product #	Product identification string
SN #	Serial number of the unit.
FW TYPE ##	Code that identifies the type of firmware used in the unit.
DRIVES #	Number of drives in the unit.
SLOTS #	Number of available storage slots in the unit.

Log Name	Description
JKBX ODOMETERS *	Press ENTER to select the odometer logs described in the next five rows.
HOURS	Number of operation hours (time the power was on). Some of the time may be while in power reduction mode.
MOVES	Total moves and move attempts by the disk transport mechanism.
FLIPS	Total disk transport mechanism flips.
XLATES	Total disk transport mechanism horizontal moves.
ROTATES	Total mailslot rotations.
DRIVE LOADS *	Press ENTER to select the logs under this selection.
DRIVE #	Total disk loads for the drive numbered “#.”
DRIVE FW *	Press ENTER to select the logs under this selection.
D# REV x.xx	Drive firmware revision code. “D#” is the drive number and x.xx is the code. Press NEXT or PREV to select drive numbers.
DRIVE SN *	Press ENTER to select the logs under this selection.
D# xxxxxxxx	Serial number of the drive where “#” is the drive number. Press NEXT or PREV to select drive numbers.
HARD ERROR *	<p>Log of unrecoverable errors (commands that did not successfully complete). Returns either NO HARD ENTRIES or ENTRY #. (There may be multiple hard error numbers.)</p> <p>Press ENTER to view the log for the currently displayed error, or press NEXT to select the next error.</p> <p>Log entries are described in the rows following RECOVERY ERROR * in this table.</p>

Retrieving Log History

Log Name	Description
SOFT ERROR *	<p>Log of recovered errors (commands that complete successfully). Returns either NO SOFT ENTRIES or ENTRY #. There may be multiple soft error numbers as a result of multiple error recoveries.</p> <p>Press ENTER to view the log for the currently displayed error, or press NEXT to select the next error. Log entries are described in the rows following RECOVERY ERROR * in this table.</p>
RECOVERY ERROR *	<p>Log of errors during the most recent move. Returns either NO ENTRIES or the number of recovery errors.</p> <p>Press ENTER to view the log for the currently displayed error, or press NEXT to select the next error. Log entries are described in the following rows.</p>
*HARDWARE ERR #	<p>Internal diagnostics error number of the cause of the failure.</p>
*FRU 1 #	<p>Field replaceable unit most likely to be at fault.</p>
*FRU 2 #	<p>Field replaceable unit second most likely to be at fault.</p>
*FRU 3 #	<p>Field replaceable unit third most likely to be at fault.</p>
MOTION <name>	<p><name> indicates one of the following types of movements taking place in the jukebox at the time of the failure:</p> <ul style="list-style-type: none"> • EXCHANGE • MOVE • POSITION • INIT ELEM • REZERO • ROTATE • DIAGNOSTIC • RESTORE

Log Name	Description
SOURCE #	Element number where the move started. Valid for MOVE, EXCHANGE, and POSITION movements only.
DESTINATION 1 #	Element where the move was directed first. Valid for MOVE and EXCHANGE movements only.
DESTINATION 2 #	Element where the move was directed second. Valid for the EXCHANGE movement only.
ODOMETER #	Move number in which the error occurred.
*MICROMOVE 1 #	First jukebox micro-move for the original move command issued prior to the failure.
*MICROMOVE 2 #	Second jukebox micro-move for the original move command issued prior to the failure.
*MICROMOVE 3 #	Third jukebox micro-move for the original move command issued prior to the failure.
*MICROMOVE 4 #	Fourth jukebox micro-move for the original move command issued prior to the failure.
*MICROMOVE 5 #	Fifth jukebox micro-move for the original move command issued prior to the failure.
*MICROMOVE 6 #	Sixth jukebox micro-move for the original move command issued prior to the failure. This is the last micro-move logged.
*MICROMOVE ER #	Micro-move error that occurred.
TOP or BOTTOM PICKER	Displays either TOP or BOTTOM indicating which side of the disk transport mechanism was active at the time of the error.
NORTH or SOUTH THUMB	Displays either NORTH or SOUTH indicating which thumb on the transport mechanism was active at the time of the error.

* Press **ENTER** to display more information

Operation and Configuration
Retrieving Log History

4 Troubleshooting and Diagnostics

Overview

This chapter gives information in the following topics:

- Troubleshooting using the control panel
- Recovery procedures for operating/installation errors
- Recovery procedures for specific hardware errors
- Micro-move error codes
- Description of robotic micro-moves
- Running internal tests

Troubleshooting Using the Control Panel

When there are errors in robotic movements, use these approaches to get information and to run exerciser tests:

- Troubleshooting Using the Control Panel and Observation - used in situations where you have a hard error.
- Troubleshooting Through the SCSI Bus - used in situations where you have an intermittent, recoverable error.

Obtaining Troubleshooting Information

Error information is available through both control panel and through the SCSI bus, using an external diagnostic tool.


In most instances, running internal tests and reading error logs in the control panel display will be enough to troubleshoot problems in the jukebox.

List of Possible Suspect FRUs

At poweron, and after every failed move, the robotics automatically run an initialization sequence that comprehensively tests the functions of the jukebox. If a hard failure occurs, a list of possible FRUs that may have been at fault is returned.

Figure 4-1

Suspect FRUs



How Suspect FRUs Are Evaluated

Similar to treating symptoms rather than the real problem, the suspect FRUs given by the FRU isolation procedure may actually mask the root cause of the problem.

The hard move error that caused the robotics to run the FRU isolation test may only be a product of the actual problem. Blindly and repeatedly replacing the suspect FRU(s) will not reliably solve a problem.

If you consider the suspect FRU as a pointer to the problem area rather than the problem itself, an educated visual inspection should reveal the real problem.

A good visual inspection requires an understanding of how the jukebox normally operates. To understand what the robotics do in normal operation, run the various movements available from the control panel and watch it closely. Reading the descriptions in the “Micro-Move ID” table in this chapter will also help you understand the small moves that comprise jukebox operation.

Recovery Procedures for Operation/Installation Errors

CAUTION

Do not cycle power until you are sure the system SCSI bus is inactive and will remain inactive. Removing power while the bus is active can cause data loss and/or indeterminate bus states. Check the host system reference manuals for information on checking the status of the SCSI bus

Table 4-1 Troubleshooting

Problem	What to do
Jukebox won't power on.	<ul style="list-style-type: none"> • Ensure that power cord connections are tight. • Ensure that the power switch is on (located on the lower right side of the jukebox rear panel). • Ensure that the power outlet is operating. • Replace the power cord with a known good one. • Check for an inoperable power supply.
Jukebox power fails or is interrupted.	<ul style="list-style-type: none"> • Take any action, as directed, by the customer's application software. • If no other actions are directed by the application software, unmount and remount all disk surfaces when power returns. <i>Do not eject any disks until the surfaces are unmounted/unreserved.</i>
Host computer power fails or is interrupted, but the jukebox power remains on.	<p>Usually you will not have to intervene unless the customer's jukebox application specifies some action.</p> <p>Ensure that a the customer's application or you do a file system check (<i>fsck</i> or equivalent) on any write-mounted surfaces after the host reboots.</p> <p><i>Do not eject any disks until the surfaces are unmounted/unreserved</i></p>

Recovery Procedures for Operation/Installation Errors

Problem	What to do
Both host computer system and jukebox power fails or is interrupted.	Same as “Host computer power fails” on previous page.
Host does not recognize the jukebox	<ul style="list-style-type: none"> • Ensure that the jukebox is supported on the host operating system. • Ensure that the jukebox is installed and configured as described in the user’s guide and the appropriate host system manuals. • Check the SCSI connections. • Check the SCSI interface address as it relates to the device files. • Power cycle the jukebox, let it come READY and then reboot the host.
Poweron selftest failed and DEVICE FAILED displays	<ul style="list-style-type: none"> • Power cycle the jukebox.* • If the poweron test continues to fail, press ENTER, record the displayed error code. Refer to Table 4-2, “Hardware Errors Verification/Recovery” for corrective action.
DEVICE FAILED displays. Hardware Error #61 (External SCSI cables) is reported.	<ul style="list-style-type: none"> • Ensure that only one SCSI device type (single-ended OR differential) exists on the SCSI bus. • Verify that the SCSI interface selection switch is set correctly (either single-ended or differential). • Verify that the terminator is the correct type (single-ended or differential). • Run the WELLNESS TEST. Record any errors and refer to Table 4-2, “Hardware Errors Verification/Recovery” for corrective action.
<p>* Ensure that the SCSI bus is inactive before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</p>	

Troubleshooting and Diagnostics
Recovery Procedures for Operation/Installation Errors

Problem	What to do
Power to the jukebox failed while a disk was in the drive and the display did not return to READY after the power came back on.	<ul style="list-style-type: none"> • Power cycle the jukebox.* • If READY does not display (poweron test is unsuccessful), display the error code and refer to Table 4-2, “Hardware Errors Verification/Recovery” for corrective action.
No display messages.	<ul style="list-style-type: none"> • Ensure that the power cord is connected. • Ensure that the power switch is on. • Ensure that the power supply and fans are operating. • Power cycle the jukebox.* • If problem remains, remove the rear panels (see Chapter 5, Figure 5-1) and check the connections to the display PCA. Power cycle the jukebox.* • If problem remains, consider changing the display PCA, controller PCA, and cables in that order.
Changed the drive ID but the new ID isn't recognized.	<ul style="list-style-type: none"> • Ensure that the new drive ID was saved (procedure was completed). • Ensure that the ID is not a duplicate of another ID on the bus. • Power cycle the jukebox.* (Some computers require a restart to recognize new SCSI IDs.)
Customer forgot the password.	<p>Restore the factory default settings:</p> <ul style="list-style-type: none"> • Hold down the ENTER and NEXT key while power cycling the jukebox* <li style="text-align: center;">or • Download the base code of the jukebox.
<p>* <i>Ensure that the SCSI bus is inactive</i> before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</p>	

Recovery Procedures for Operation/Installation Errors

Problem	What to do
Disk inserted in the mailslot but LOAD ERROR or FAILED displays.	<ul style="list-style-type: none"> • Press CANCEL. Insert the disk in the mailslot again. See “Loading an Optical Disk into the Jukebox” in this chapter for the correct disk loading orientation. • If the light bar on the front panel is orange, cycle power to the jukebox.* Try to load the disk again when READY displays. • Check to see if the mailslot rotates in. If the mailslot does not rotate in, the mailslot cabling or sensors may be the cause. Remove the mailslot assembly and check the mailslot cabling (refer to Chapter 5, “Replacing the Mailslot Assembly”). If the cables are good, replace the mailslot assembly.
Disk inserted in the mailslot but RESERVED displays	<p>The SECURE MS configuration is set. Disks cannot be loaded.</p> <ul style="list-style-type: none"> • If appropriate, change this setting. See “Setting an Operating Configuration” in Chapter 3. The current administration password is required.
Disk inserted in the mailslot but MAIL SLOT EMPTY displays	<p>The mailslot sensors do not detect a disk in the mailslot.</p> <ul style="list-style-type: none"> • Remove and reinsert the disk. If the same error reappears, the mailslot sensors may be defective.
Disk inserted in the mailslot but DEST NOW FULL displays	<p>The jukebox moved a disk into the slot you chose before your load command executed.</p> <ul style="list-style-type: none"> • Press CANCEL, select another slot for the disk, and then reattempt a load. • If the jukebox is not in use, run INIT ELEM STATUS. Refer to Table 4-2, “Hardware Errors Verification/Recovery” for corrective actions.
<p>*Ensure that the SCSI bus is inactive before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</p>	

Troubleshooting and Diagnostics
Recovery Procedures for Operation/Installation Errors

Problem	What to do
Disk inserted in the mailslot but TRANSPORT FULL displays	<p>The disk transport mechanism already contains a disk.</p> <ul style="list-style-type: none"> • Select EJECT. If the disk is not ejected from the transport mechanism and you receive the same error, run the EMPTY PICKER TEST. • If problem remains, refer to the host and application documentation for recovery procedures.
Disk inserted in the mailslot but MAILSLOT SENSOR displays	<p>The jukebox mailslot sensors may have failed.</p> <ul style="list-style-type: none"> • Remove and then re-insert the disk. • If problems remain, check the mailslot sensors.
Disk eject attempted but an EJECT ERROR message displays.	<ul style="list-style-type: none"> • Press CANCEL. Attempt to eject the disk again. • If the light bar on the front panel is orange, cycle power to the jukebox* and try to eject the disk again when READY displays. • If there is no disk in the mailslot and this error message repeats, check the connections to the mailslot.
Disk eject attempted but RESERVED displays.	<p>The jukebox application software reserved the element for its use or a security configuration was set to prevent disk ejection.</p> <ul style="list-style-type: none"> • If appropriate, change this setting See “Setting an Operating Configuration” in Chapter 3. The current administration password is required.
Disk eject attempted but EMPTY and then EJECT * displays.	<p>This is not an error. There are no disks in the jukebox.</p>
<p><i>*Ensure that the SCSI bus is inactive before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</i></p>	

Recovery Procedures for Operation/Installation Errors

Problem	What to do
Disk eject attempted but <code>TRANSPORT FULL</code> displays.	<p>The disk transport mechanism already contains a disk.</p> <ul style="list-style-type: none"> • Run the <code>EMPTY PICKER TEST</code>. • If problem remains, refer to the host and application documentation for recovery procedures.
Disk eject attempted but <code>SOURCE NOW EMPTY</code> displays.	<p>The application software moved the disk from the slot you chose before your eject command executed.</p> <ul style="list-style-type: none"> • Press CANCEL. You may have to wait for the application to replace the disk into the slot before attempting another eject. • If the jukebox is not in use, run <code>INIT ELEM STATUS</code>. Refer to Table 4-2, “Hardware Errors Verification/Recovery” for corrective actions.
Disk eject attempted but <code>MAILSLOT FULL</code> displays.	<p>A disk is in the mailslot.</p> <ul style="list-style-type: none"> • Select <code>EJECT *</code>, select the slot you want the disk ejected from again, and eject the disk.
You want to stop a test that is running.	<p>Press CANCEL. The current test loop continues until finished, then the test stops.</p>
<p><i>*Ensure that the SCSI bus is inactive before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</i></p>	

Troubleshooting and Diagnostics
Recovery Procedures for Operation/Installation Errors

Problem	What to do
RUN ISTAT TEST displays (this initializes the element status)	<p>RUN ISTAT TEST initializes the element status.</p> <ul style="list-style-type: none"> • Power cycle the jukebox.* • Run the INIT ELEM STATUS test from the TEST *menu.. • If the same display occurs, run the WELLNESS TEST. Do general troubleshooting.
Can't write to the disk.	<ul style="list-style-type: none"> • Check the host file system access permissions. • Eject the disk and check that the write-protect tab on each side of the disk is in the write-enabled position. • Check the application software. • Run online/offline diagnostics on drive.
<p><i>*Ensure that the SCSI bus is inactive before removing power to the jukebox. Removing power to a device on an active SCSI bus can cause data loss and/or problems with the SCSI interface.</i></p>	

Recovery Procedures for Specific Hardware Errors

When a hardware failure occurs, a message displays on the control panel. If the failure occurs during the poweron sequence, `DEVICE FAILED` displays. If the failure occurs when loading a disk you may see `LOAD ERROR`, or `FULL`. If a failure occurs while you are running a test, `TEST FAILED` displays. When you press **ENTER**, the jukebox displays information about the hardware failure from the error log.

The jukebox firmware can detect broken components such as a dead motor, but if failures are due to marginal or random problems, the failing component may induce errors in other components. For example, if the electronics produce an intermittent error or if friction increases on a part, different components of the jukebox may appear to fail. Several error codes may be displayed as a result of one problem.

The following table shows the hardware error codes possible and recovery procedures for specific hardware errors.

Table 4-2

Hardware Errors Verification/Recovery

Error Code (hex)	Verification/Recovery Procedures
01 ROM checksum error	Errors 01 to 07 are only possible on powerup. errors only possible on powerup. Replace the controller PCA.
02 Register error	See error 01.
03 Microprocessor error	See error 01.
04 Controlled area of RAM checksum error	See error 01.
05 RAM test error	See error 01.

Troubleshooting and Diagnostics
Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
06 SCSI chip error	See error 01..
07 Jukebox controller chip error	See error 01.
11 Drive serial communications failure	<ol style="list-style-type: none"> 1. Check that the drive communication cable to the interposer PCA is firmly connected. 2. Change the affected drive.
1E Translate motor error	<p>Cannot translate the picker and/or sense that it has moved.</p> <ol style="list-style-type: none"> 1. Run FIND XLAT HOME test from the control panel. 2. If the picker does not move at all, check the connections on the umbilical cable. If the connections are good and the picker still does not move, change the umbilical cable. 3. If the picker moves a little but does not reach the side of the frame, the translate motor on the picker is probably defective. Change the picker. 4. If the picker moves properly to the side, the translate sensor is probably defective. Change the picker.

Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
<p>1F Vertical motor error</p>	<p>Occurs when trying to sense a move of the carriage assembly.</p> <ol style="list-style-type: none"> 1. If the translate assembly moves -- and you get a failure -- that means that we're not reading the encoder strip. Make sure the encoder strip is inside sensor. 2. If the translate assembly doesn't move -- it probably is the motor leads, motor, or 24-volt power supply. <ol style="list-style-type: none"> a. Make sure the motor leads are connected to the vertical motor. b. Check that the cable from the sensor is connected through the translate frame to the umbilical cable for the picker. c. Change the vertical motor. d. Change the 24-volt power supply. 3. Change the controller PCA.
<p>20 Plunge motor error</p>	<ol style="list-style-type: none"> 1. 2. Change the jukebox controller PCA 3. Change the picker 4. Check the plunge motor leads
<p>28 Mailslot sensor error</p>	<ol style="list-style-type: none"> 1. Run the Mailslot I/O Test to see if sensors are registering or if they are intermittent 2. Check the mailslot-to-interposer cable. 3. Change the interposer PCA. 4. Change the mailslot.
<p>2B Top thumb sensor error</p>	<ol style="list-style-type: none"> 1. Change the picker. 2. Change the umbilical cable. 3. Change the controller PCA.

Troubleshooting and Diagnostics
Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
2C Bottom thumb sensor error	<ol style="list-style-type: none"> 1. Change the picker. 2. Change the umbilical cable. 3. Change the controller PCA.
32 Invalid test number	User error.
33 Invalid configuration	<p>User error.</p> <p>There might not be enough cartridges in the jukebox.</p>
34 Need to initialize element status	Run Init Elem Status.
35 Exercise test failed	Run Exercise test again, watch where it fails. Continue troubleshooting from the movement/operation that failed.
36 Elements reserved	<p>User error.</p> <p>The host probably has the jukebox elements reserved.</p>
3C Move to	<p>Vertical motion failed in the middle of a move or exchange</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO *, and Hardware Error in the control panel display). Also check the Source and Destination entries in the error log to verify what move was in process. 2. Make sure the encoder strip is inside sensor 3. Make sure the motor leads are connected to the vertical motor. 4. Check that the cable from the sensor is connected through the translate from to the umbilical cable for the picker.

Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
3D Flip	Change the picker.
3E Translate	Change the picker.
3F Put cartridge in	<p>Failed plunging cartridge into a slot</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display). 2. Check that the picker assembly looks normal and is in the proper orientation. 3. Check that the picker is in the proper height with respect to the storage slot and that the vertical encoder strip is not damaged.
40 Get cartridge out	<p>Failed extracting a cartridge from a slot.</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display). 2. Check that the picker assembly looks normal and is in the proper orientation. 3. Check that the picker is in the proper height with respect to the storage slot and that the vertical encoder strip is not damaged.

Troubleshooting and Diagnostics
Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
41 Test magazine	<p>Failed testing the magazine portion during an ISTAT.</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display) 2. Check that the picker assembly looks normal and is in the proper orientation. 3. Check that the picker is in the proper height with respect to the storage slot and that the vertical encoder strip is not damaged.
42 Put cartridge in a drive	<p>Failed inserting a cartridge into a drive.</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display). 2. Remove rear panel and run the Wellness Test, Drive I/O test, and Exercise Mechanics test. Note where the problem occurs. If indicates the drive, change the drive. If it indicates a picker error, change the picker.
43 Get cartridge from a drive	<p>Failed extracting a cartridge from a drive.</p> <ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display). 2. Remove rear panel and run the Wellness Test, Drive I/O test, and Exercise Mechanics test. Note where the problem occurs. If indicates the drive, change the drive. If it indicates a picker error, change the picker.

Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
44 Test drive	<ol style="list-style-type: none"> 1. Look at the micro-move error of the failure in the error log (under INFO * and Hardware Error in the control panel display). 2. Remove rear panel and run the Wellness Test, Drive I/O test, and Exercise Mechanics test. Note where the problem occurs. If it indicates the drive, change the drive. If it indicates a picker error, change the picker.
45 Put mailslot in	<ol style="list-style-type: none"> 1. Cycle power to the jukebox to initiate a poweron test sequence. 2. Check to see if mailslot rotation works. If the mailslot rotates in, change the picker. If the mailslot does not rotate in, change the mailslot.
46 Get mailslot out	<ol style="list-style-type: none"> 1. Cycle power to the jukebox to initiate a poweron test sequence. 2. Check to see if mailslot rotation works. If the mailslot rotates in, change the picker. If the mailslot does not rotate in, change the mailslot.
47 Test mailslot	<ol style="list-style-type: none"> 1. Cycle power to the jukebox to initiate a poweron test sequence. 2. Check to see if mailslot rotation works. If the mailslot rotates in, change the picker. If the mailslot does not rotate in, change the mailslot.
48 Rotate mailslot in	<ol style="list-style-type: none"> 1. Cycle power to the jukebox to initiate a poweron test sequence. 2. Check to see if mailslot rotation works. If the mailslot rotates in, change the picker. If the mailslot does not rotate in, change the mailslot.
49 Rotate mailslot out	<ol style="list-style-type: none"> 1. Cycle power to the jukebox to initiate a poweron test sequence. 2. Check to see if mailslot rotation works. If the mailslot rotates in, change the picker. If the mailslot does not rotate in, change the mailslot

Troubleshooting and Diagnostics
Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
4A Test picker	This may appear when testing for a cartridge in the picker during an ISTAT. Replace the picker.
4B Switch active picker	<ol style="list-style-type: none"> 1. Check for loose cables 2. Replace the picker.
4C Restore picker	<ol style="list-style-type: none"> 1. Check for loose cables 2. Replace the picker.
4D Find translate home	<p>Cannot translate the picker and/or sense that it has moved.</p> <ol style="list-style-type: none"> 1. Run FIND XLAT HOME test from the control panel. 2. If the picker does not move at all, check the connections on the umbilical cable. If the connections are good and the picker still does not move, change the umbilical cable. 3. If the picker moves a little but does not reach the side of the frame, the translate motor on the picker is probably defective. Change the picker. 4. If the picker moves properly to the side, the translate sensor is probably defective. Change the picker.
4E Find vertical home	<p>Because a motor test is called before a “find vertical home” is attempted, the vertical motor is assumed to be at least minimally functional</p> <ol style="list-style-type: none"> 1. Check that the vertical path is physically clear. 2. Make sure that the cartridges are fully inserted into their slots. 3. Change the vertical motor.

Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
4F Find plunge home	Change the picker.
50 Clear flip area	<p>The vertical path is probably blocked and the picker might be falsely overforcing.</p> <ol style="list-style-type: none"> 1. Check that the path is clear. 2. Exercise and visually check the operation of the vertical motor.
51 Clear magazine path	<ol style="list-style-type: none"> 1. Check that the path from the picker to the magazine is clear. 2. Check that the vertical path is clear. 3. Test the vertical path sensor operation.
52 Clear drive path	<ol style="list-style-type: none"> 1. Check that the path from the picker to the drive is clear. 2. Check that the vertical path is clear. 3. Test the vertical path sensor operation.
53 Clear mailslot path	<ol style="list-style-type: none"> 1. Check that the path from the picker to the drive is clear. 2. Check that the vertical path is clear. 3. Test the vertical path sensor operation.
5B Finish switching the picker	Change the picker.
5C Wait plunge	Change the picker.

Troubleshooting and Diagnostics
Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
5D Wait vertical	Vertical motion failed in the middle of a move or exchange. <ol style="list-style-type: none">1. Look at the micro-move error of the failure in the error log (under INFO * [Hardware Errors] in the control panel display). Also check the Source and Destination entries in the error log to verify what move was in process.2. Make sure the encoder strip is inside sensor.3. Make sure the motor leads are connected to the vertical motor.4. Check that the cable from the sensor is connected through the translate from to the umbilical cable for the picker.
5E Powerfail clear path	<ol style="list-style-type: none">1. Check that all paths are clear.2. Test the vertical path sensor operation.

Recovery Procedures for Specific Hardware Errors

Error Code (hex)	Verification/Recovery Procedures
5F Powerfail restore cartridges	A cartridge was physically moved after powerfail and before powerfail recovery. Check that no cartridges have been moved.
60 Repeater Controller	<ol style="list-style-type: none"> 1. Check cables between the controller PCA and the SCSI repeater PCA. 2. Check the external cables. 3. Change repeater PCA. 4. Change the controller PCA. 5. Change internal SCSI cable
61 External SCSI cables	<ol style="list-style-type: none"> 1. Check for correct terminator (single-ended or differential) for the type of SCSI interface chosen. 2. Check that single-ended / differential slide switch is selecting desired interface. 3. Change external SCSI cable. 4. Change SCSI repeater PCA. 5. Change the controller PCA

Micro-Move Error Codes

Table 4-3

Micro-Move Error Codes

Micro-Move Error Code (hex)	Description
01	Vertical over voltage exceeded limit set by firmware
02	Vertical over force exceeded limit set by firmware
03	Vertical servo error
04	Vertical time-out
05	Vertical open path
06	Vertical closed path
0A	Plunge over voltage exceeded limit set by firmware
0B	Plunge over force exceeded limit set by firmware
0C	Plunge servo error
0D	Plunge servo error
0E	Plunge open path
0F	Plunge closed path
10	Top picker expected to be active picker in plunge (run-time)
11	Bottom picker expected to be active picker in plunge (run-time)
12	Bottom thumb expected to be active in plunge home (powerup)
13	Top thumb expected to be active in plunge home (powerup)
14	Translate over voltage exceeded limits set by firmware
15	Translate over force exceeded limits set by firmware

Troubleshooting and Diagnostics

Micro-Move Error Codes

Micro-Move Error Code (hex)	Description
16	Translate servo error
1E	No load complete
1F	Unexpected load complete
20	Unexpected cartridge in drive
21	No cartridge in drive
22	Drive put in accept failed
23	Drive get out accept failed
24	Drive eject failed
25	Drive insert failed
26	Drive eject retry
27	Drive insert retry
28	Clear drive path
29	Drive signal (not used)
2A	Drive not connected
32	Magazine put in saturate failed
33	Magazine get out saturate failed
34	Magazine put in accept failed
35	Magazine get out accept failed
36	Magazine measure failed
37	Test magazine failed
38	Return magazine failed
39	Clear magazine path
3C	Mailslot put in saturate failed

Micro-Move Error Code (hex)	Description
3D	Mailslot get out saturate failed
3E	Mailslot put in accept failed
3F	Mailslot get out accept failed
40	Measurement of mailslot depth failed
41	Recovery did not clear vertical path
42	Rotate mailslot in failed
43	Rotate mailslot out failed
46	Flipped too far
47	Did not flip far enough
48	Flip side incorrect
50	Failed to finish a translate
51	Extra force needed to translate
5A	Command received to rotate mailslot but both pickers are full
5B	Back sensor in mailslot is bad
5C	Front sensor in mailslot is bad
5D	Command received to eject from the mailslot, but both pickers are full
5E	Attempt to load from an empty mailslot
5F	Engaging the mailslot failed on a rotate in
60	Disengaging the mailslot failed on a rotate in
61	Rotate in catch error (not used)
62	Rotate in push out error (not used)
63	Rotate in armed failed (not used)

Micro-Move Error Codes

Micro-Move Error Code (hex)	Description
64	Did not detect hard stop on a rotate in
65	Rotate in was too much distance
66	Engaging the mailslot failed on a rotate out
67	Disengaging the mailslot failed on a rotate out
68	Did not detect hard stop on a rotate out
69	Rotate out distance was too short
6A	Could not move thumbs out of the vertical path after a rotate out
6B	Vertical distance difference detected after error recovery
6C	Cartridge in mailslot incorrectly at rotate in

Description of Micro-Moves

Table 4-4 Micro-Move IDs and Expanded Descriptions

Micro-Move ID (hex)	Description
1	Move picker transport up. Fast.
2	Move picker transport down. Fast.
3	Move picker transport up slowly, checking for resistance. Used in the vertical find home sequence.
4	Move picker transport down slowly, checking for resistance. Used in the vertical find home sequence.
5	Move a small amount upward to relieve tension in the servos. Used after finding “home” in the vertical find home sequence.
6	Make a small vertical movement as a plunge is made into a drive. Used to “wobble” the picker during error recovery.
8	Move picker transport up to the top of the jukebox, checking for a clear path. Used in the vertical find home sequence.
9	Move picker transport to the bottom of the jukebox, checking for a clear path. Used in the vertical find home sequence.
11	Move slowly up far enough to establish that there is enough room to flip the picker. Used in the plunge find home sequence.
12	Move slowly down far enough to establish that there is enough room to flip the picker. Used in the plunge find home sequence.
13	Move slowly to the flip clear area (determined in micro-moves 11 and 12). Used in the plunge find home sequence. Also used in power fail recovery to move the picker off of a cartridge that was between the picker and the magazines when the power failed and the picker settled.

Description of Micro-Moves

Micro-Move ID (hex)	Description
14	Move slowly downward to the flip clear area (determined in micro-moves 11 and 12). Used in the plunge find home sequence.
15	Move vertically to restore the picker to the position it had before an error (and error recovery, occurred. Only called in error recovery.
16	Move up. Used in the motor test during powerup.
17	Move down. Used in the motor test during powerup.
62	Move slowly to one side of the translate frame. Used to find translate home during powerup. Movements after powerup use the translate home ID, 63.
63	Move to one side of the translate frame. Used to find translate home.
67	Move a short distance back from the plunge position where an overforce shutdown error occurred. Relaxes the tension.
68	Retract the plunge assembly on the picker all the way back to find “home” in the plunge axis. May start a flip, depending on starting position. (One of three plunge find homes in the sequence; 68, 69, 6A).
69	Retract the plunge assembly on the picker all the way back and flip the picker at the same time. Used to find “home” in the plunge axis. (One of three plunge find homes in the sequence; 68, 69, 6A).
6A	Retract the plunge assembly on the picker all the way back and then flip the picker. Used to find “home” in the plunge axis. Second flip of the sequence. (One of three plunge find homes in the sequence; 68, 69, 6A).
6B	Plunge toward magazine to get cartridge.
6C	First time plunge into magazine (first “get”). Feels for resistance to learn the distance to the cartridge when it is seated.

Micro-Move ID (hex)	Description
6D	Retraction to pull the cartridge out of the magazine.
6F	First part of a two-step move to put a cartridge into a magazine. Puts the cartridge nearly all the way in. Next part of move is micro-move 70.
70	Second part of a two-step move to put a cartridge into a magazine. Continues movement of micro-move 6F and puts the cartridge in the rest of the way (the distance learned in micro-move 6C).
71	First time plunge into a magazine (first “put”). Feels for resistance to learn the distance to the cartridge when it is seated.
72	Retract picker plunge assembly after putting cartridge into a magazine. Assembly is retracted just far enough that the thumbs are clear of the picker vertical path.
75	First part of a two-step plunge move to put a cartridge into a drive. Cartridge is inserted to a point where the drive shutter arms start to engage.
76	First time “put” plunge into a drive. Slow. Feels for resistance to learn the distance to the cartridge when it is seated.
77	First time “get” plunge into a drive. Slow. Feels for resistance to learn the distance to the cartridge when it is seated.
78	Fast “put” plunge into a drive (distance has been previously learned).
79	Retract picker plunge assembly after putting cartridge into drive. Assembly is retracted just far enough to that the thumbs are clear of the picker vertical path.
7C	(Used in an emergency cartridge eject). Plunge toward a drive, stopping at a position close to the drive. This the wait position until the drive ejects the cartridge.

Description of Micro-Moves

Micro-Move ID (hex)	Description
7D	(Used in an emergency cartridge eject). Plunge to contact and get the cartridge from the drive. Follows micro-move 7C.
7E	Log ID (no motion). Logs that picker is in position in front of drive, waiting for the drive to eject the cartridge.
7F	Plunge forward to get cartridge from the drive. Thumbs wrap over the ears on the cartridge.
80	Retract a small amount to take up the slack between the picker thumbs and the cartridge ears.
81	Retract plunge assembly fully back into the picker.
83	Flip during plunge when cartridge is in the top picker.
84	Flip during plunge when cartridge is in the bottom picker.
87	Short plunge out to test for a cartridge in the picker. If a cartridge is in the picker, the path clear beam will be interrupted. Used in an ISTAT.
88	Short plunge out to test for a cartridge in a magazine when the picker contains a cartridge. If resistance is felt, this is interpreted as a cartridge in the magazine. Used in an ISTAT.
89	Retract picker plunge assembly into the picker after executing micro-move 88. Used in an ISTAT.
8A	Short plunge to test for a cartridge in a drive when the picker contains a cartridge. If resistance is felt, this is interpreted as a cartridge in the drive. Used in an ISTAT.
8B	Plunge out. Used in error recovery. Is an attempt to push a cartridge out of the vertical picker path and into a magazine.
8C	Retract thumbs back into the picker. Used in error recovery. Is an attempt to pull a cartridge out of the vertical picker path and into the picker. Either this micro-move or micro-move 8D is used, depending on position of the picker at the start of recovery.

Micro-Move ID (hex)	Description
8D	Retract thumbs back into the picker. Used in error recovery. Is an attempt to pull a cartridge out of the vertical picker path and into the picker. Either this micro-move or micro-move 8C is used, depending the on the position of the picker at the start of recovery.
8E	Move picker plunge assembly out to rearm the picker mechanism before switching active picker.
8F	Retract picker plunge assembly to a point just short of tripping the thumb selection mechanism. First of two steps (second step is micro-move 90).
90	Retract picker fingers all the way back. Trips the mechanism that makes the opposite thumb “active.”
91	Move picker plunge assembly forward, away from the full retracted position. Clears the tripping mechanism and makes the new thumb “active.”
92 to 95	Factory use only. Does not run in normal operating code.
98 to 9F	Factory use only. Does not run in normal operating code.
A2	First of two plunge movements toward the drive during error recovery. Vertical movement is done before the second part of this movement (micro-move A3) is done.
A3	Second of two plunge movements toward the drive during error recovery. Done after a small vertical movement is done to “wobble” the picker.
A4	Plunge out. Is an attempt to clear the vertical picker path during drive error recovery.

Description of Micro-Moves

Micro-Move ID (hex)	Description
A5	Retract picker. Is an attempt to clear the vertical picker path during drive error recovery.
A5	First part of a two-step move to fully retract the picker plunge assembly. Retract assembly almost all the way back. Next part of move is micro-move A6.
A6	Second part of a two-step move to fully retract the picker plunge assembly. Continues movement of micro-move A5 and brings picker plunge assembly all the way back.
A7	Move picker plunge assembly forward a small amount from full retracted position. Completes rearm of the picker mechanism.
A8	Move to a position where the picker thumb sensor can be read. Used in the find plunge home recalibration.
A9	Move to a position where the current active picker can be read. Used in the plunge home recalibration.
AA	Fully retract picker plunge assembly to switch the active picker. One of three moves used to make the top picker the active picker during a picker recalibration.
AB	Move picker plunge assembly forward a small amount to complete the rearm of the picker mechanism. One of three moves used to make the top picker the active picker during a picker recalibration.
AC	Move picker plunge assembly forward to normal position after a active picker has been change by micro-moves AA and AB. One of three moves used to make the top picker the active picker during a picker recalibration.
AD	Move the picker plunge assembly a small amount away from the flip mechanism so that the mechanism is rearmed for a flip. Used in a flip sequence.
AE	Move the picker plunge assembly out a small amount from the full retracted position to relieve the pressure on the mechanism after a flip.

Micro-Move ID (hex)	Description
AF	First of two moves to move the thumb to the magazine during an ISTAT when no cartridge is in the picker. Next move is micro-move B0.
B0	Second of two moves to move the thumb to the magazine during an ISTAT when no cartridge is in the picker. Slow move to check for an overforce (cartridge in the magazine slot).
B1	Retract picker plunge assembly back into the picker to a point where the thumbs can unsplay. Used during an ISTAT, with no cartridge in the picker, when the thumbs are splayed and are they must be unsplayed.
B2	Retract picker plunge assembly into the picker to a point just short of where the thumbs would be released and unsplay. Used during an ISTAT, with no cartridge in the picker, when the thumbs are splayed and must be kept splayed.
B3	Retract picker plunge assembly back far enough to release the thumbs and let them go to an unsplayed position. Used during an ISTAT, and the thumbs are being returned to an unsplayed position after contacting, grabbing, and replacing the first cartridge.
B4	Retract picker plunge assembly into the picker to a point just short of where the thumbs would be released and unsplay. Used during an ISTAT, and the thumbs are being retained in the splayed position after contacting, grabbing, and replacing the first cartridge.
B5	Retract picker plunge assembly far enough to get the thumbs out of the vertical picker path. Used during an ISTAT, no cartridge in the picker, and no cartridge was contacted in the first magazine.
B6	Pull picker plunge assembly fully back to rearm a “put.” Enable the picker to replace the cartridge it picked up during an ISTAT.

Description of Micro-Moves

Micro-Move ID (hex)	Description
B7	First of two moves that put a cartridge back into the magazine after the cartridge is detected during an ISTAT. Moves the cartridge almost fully into the magazine. Followed by micro-move B8.
B8	Second of two moves that put a cartridge back into the magazine after the cartridge is detected during an ISTAT. Moves the cartridge fully into the magazine.
B9	Second of two moves to test for the presence of a cartridge in a magazine during an ISTAT when there is a cartridge in the picker. Slow move to check for an overforce (cartridge in the magazine slot). Follows micro-move BA.
BA	First of two moves to test for the presence of a cartridge in a magazine during an ISTAT when there is a cartridge in the picker. Fast plunge that places the cartridge and the picker close to the magazine. Followed by micro-move B9.
BB	Testing for media in picker. After the physical force check.
BC	Retract picker plunge assembly after detecting a cartridge in the drive. Used in an ISTAT when there is a cartridge in the picker.
BD	Retract picker plunge assembly to a point just short of where the thumbs would be released from their splayed position. Used if thumbs are splayed after checking magazines in an ISTAT.
BE	Retract picker plunge assembly after inserting a cartridge into a drive.
BF	Quickly retract the picker plunge assembly if an error occurred while inserting a cartridge into a drive.
C0	Retract picker plunge assembly to a point where the thumbs are released and go to an unsplayed position. Used in an ISTAT.
C1	Insert cartridge into a drive, just past the shutters. Distance has not been learned.

Micro-Move ID (hex)	Description
C2	Insert cartridge into a drive, just past the shutters. Distance has not been learned. Part one of a two-stage move. Used in the sequence to return a cartridge into a drive after an emergency eject during an ISTAT.
C3	Insert cartridge into a drive, just past the shutters. Distance has been learned. Part one of a two-stage move. Used in the sequence to return a cartridge into a drive after an emergency eject during an ISTAT.
C4	Insert cartridge fully into a drive. Distance HAS been learned. Part two of a two-stage move. Used in the sequence to return a cartridge into a drive after an emergency eject during an ISTAT.
C5	Insert cartridge fully into a drive. Distance HAS been learned. Additional push in case the drive acknowledge signal was not seen. Used in the sequence to return a cartridge into a drive after an emergency eject during an ISTAT.
C6	Insert cartridge fully into a drive. Distance HAS been learned. Part two of a two-stage move. Used in the sequence to return a cartridge into a drive after an emergency eject during an ISTAT.
C7	Retract picker to rearm position to splay the fingers. Used when an error in the drive acknowledge signal is seen and a drive eject will be done and the thumbs must be in the splayed position.
C8	Plunge thumbs out close to the end of the picker to get ready to “get” a cartridge. Done at the same time as vertical moves and in-transit translates and flips.
C9	Same as micro-move C8 but is a retry (if needed)
CB	Retract picker plunge assembly back far enough to clear the thumbs from the vertical picker path. Used after a cartridge is put in the mailslot.

Description of Micro-Moves

Micro-Move ID (hex)	Description
CC	Plunge out to clear the mailslot path. Distance has not been learned. Used in error recovery.
CD	Short plunge out to fully seat a cartridge in the mailslot and to measure the distance of a fully-inserted cartridge.
CE	Plunge out to clear the mailslot path. Used in error recovery.
CF	Retract picker plunge assembly in an attempt to clear the mailslot path. Used in error recovery.
DO	Short plunge to push the cartridge to a fully seated position during a “get” to the mailslot. Distance is learned.
D1	Short plunge during a mailslot “put.” Ducks under the mailslot rotation mechanism and positions the picker so it can move up all the way to mailslot insertion position.
D2	Short plunge to put the cartridge all the way into the mailslot.
D3	Short plunge during a mailslot “get”. Ducks under the mailslot rotation mechanism and positions the picker so it can move up all the way to the mailslot “get” position.
D4	Plunge to get the cartridge from the mailslot.
D5	Retract cartridge most of the way into the picker. Positions the picker so that it can duck under the mailslot rotation mechanism during a “get.”
D6	Continue retraction in micro-move D5. Pull cartridge all the way back into the picker.
D7	Retract thumbs to a point just inside the picker. Used to clear the vertical picker path during error recovery.
D8	Plunge to a position where the mailslot rotation actuator can be pulled in.
D9	Plunge to a position where the mailslot rotation actuator can be pushed out.

Micro-Move ID (hex)	Description
DA	Move picker plunge assembly to a position where the mailslot rotation actuator can be engaged to rotate the mailslot out. Used when the state of the mailslot is unknown and must be placed in a known state.
DB	Retract the picker plunge assembly a short distance to clear the thumbs away from the mailslot after rotating the mailslot out.
DC	Slow retract of the picker plunge assembly, pulling the mailslot in. Checks that the cartridge is in properly. First move of a rotate in.
DD	Retract thumbs back into the picker after rotating the mailslot out.
E1	First of two moves rotating the mailslot in. Quickly retract the picker plunge assembly, pulling the mailslot most of the way in. Followed by micro-move E3.
E2	Plunge out to rotate the mailslot almost all the way out.
E3	Short retraction of the picker plunge assembly until pressure is felt. Used at end of rotating the mailslot in and ensures that the mailslot has been rotated fully in.
E4	Short plunge out to relieve the pressure after rotating the mailslot in.
E5	Short plunge out, feeling for pressure, to ensure that the mailslot is rotated all the way out.
E6	Retract picker plunge assembly a short distance to relieve the pressure after micro-move E5.
E7	On powerup, testing for motion in one direction on the plunge motor.

Description of Micro-Moves

Micro-Move ID (hex)	Description
E8	On powerup, testing for motion in the plunge motor. Opposite direction than in micro-move E7.
E9	Plunge out to clear the picker vertical path. Used when path is blocked during powerup.
EA	Picker plunge assembly retraction to clear the picker vertical path. Used when path is blocked during powerup.

Running an Internal Test

READY > ADMIN * >TEST *

Start with READY in the display.

1. Press **NEXT** until ADMIN * displays.

2. Enter the administration password.

You may have to coordinate with the system administrator to enter the password.

3. TEST * displays. Press **ENTER**.

4. Press **NEXT** until the name of the test you wish to run displays and then press **ENTER** to start the test.

NOTE

You may press **CANCEL** at any time to abort a test. A delay may occur while the current test loop completes.

Table 4-5

Internal Tests

Test Name	Description
EXCHANGE DEMO	<i>Do not run this test if the jukebox contains disks with customer data.</i> This test moves randomly-chosen optical disks to random storage slot locations. This test displays FAIL if there are no disks in the jukebox or if all storage slots are full. For best results, the jukebox should contain as many disks as there are drives, plus two additional disks. The transport and mailslot must be empty.
INIT MECHANICS	Runs the FIND PLUNGE HOME, FIND VERTICAL HOME, FIND XLATE HOME, and INIT ELEM STATUS tests. Each test is run one time per test loop.
INIT ELEM STATUS	Physically scans the entire unit to determine which storage slots contain disks and if the drives contain disks. NOTE: This test appears as "ISTAT TEST" in all control panel error messages.

Troubleshooting and Diagnostics

Running an Internal Test

Test Name	Description
MAGAZINE IO	Makes a combination of moves with a PASS/FAIL result. It moves an optical disk from a randomly-chosen full slot to a randomly-chosen empty slot with a random flip. It then moves the disk back to its original storage slot with its original orientation. This test displays FAIL if there are no disks in the jukebox or if all storage slots are full. The drives and mailslot must be empty.
DRIVE IO	Makes a combination of moves with a PASS/FAIL result. It moves an optical disk from a randomly-chosen full slot to a randomly-chosen drive with a random flip. It then moves the cartridge back to its original slot with its original orientation. This test displays FAIL if there are no disks in the jukebox or if all storage slots are full. The drives and mailslot must be empty.
MAILSLOT IO	Makes a combination of moves with a PASS/FAIL result. It moves an optical disk from the lowest-numbered full slot to the mailslot with a random flip. It then moves the cartridge back to its original slot with its original orientation. This test displays FAIL if there are no disks in the jukebox or if all storage slots are full. The drives and mailslot must be empty.
VERTICAL TEST	Moves the disk transport mechanism up and down the full length of the rail. Returns PASS/FAIL. No disks are required.
TRANSLATE TEST	Moves the disk transport mechanism from side to side. No disks are required.
FLIP TEST	Makes a combination of moves with a PASS/FAIL result. Flips the disk transport mechanism at various locations. No disks are required.
PICKER TEST	Flips the disk transport mechanism and switches active thumbs. No disks are required.

Test Name	Description
FIND PLUNGE HOME	Calibrates the disk transport mechanism, establishes the mechanism's orientation, and determines the reference points in the picker travel path. Assumes that the mechanics and servo system are functional. No disks are required.
FIND VERT HOME	Recalibrates the vertical position of the disk transport mechanism and verifies that the vertical path is clear. No disks are required.
FIND XLATE HOME	Calibrates the reference points for the side-to-side motion of the disk transport mechanism. No disks are required.
VERTICAL ENCODER	Moves the disk transport mechanism down to the lower stop, moves it back up a short distance, and then moves it back down. On the second downward motion the number of digital pulses is counted and verified. Returns PASS/FAIL. No disks are required.
EMPTY DRIVES	<i>Do not run this test if the jukebox contains disks with customer data.</i> Moves disks out of the drive mechanism(s) and returns them to their home storage slot locations if the locations are known. If the home storage location is not known, the jukebox moves the disks into the first available empty storage slot.
EMPTY PICKER	<i>Do not run this test if the jukebox contains disks with customer data.</i> Moves a disk from the disk transport mechanism to its home storage slot location if that location is known, otherwise the disk is placed into the first available empty storage slot.
FILL PICKER	<i>Do not run this test if the jukebox contains disks with customer data.</i> Moves a disk into the disk transport mechanism from the first storage slot containing a disk. This test must be run twice to fill both containers in the disk transport mechanism.

Troubleshooting and Diagnostics

Running an Internal Test

Test Name	Description
EXERCISE MECH	Runs the VERTICAL TEST, TRANSLATE TEST, FLIP TEST, MAGAZINE IO, DRIVE IO, and MAILSLLOT IO tests. Each test runs one time per test loop.
WELLNESS TEST	Checks the general capability of the jukebox. Requires one loaded disk. The drives, transport, and mailslot must be empty. Runs INIT MECHANICS and EXERCISE MECHANICS. Each test runs one time per test loop.
CLEAR SOFT LOG	Sets the soft error log to zero.
CLEAR HARD LOG	Sets the hard error log to zero.
PLUNGE FULL SPD	Allows the disk transport mechanics to run at full speed. This setting should always be used in normal jukebox operation.
PLUNGE 1/2 SPD	Allows the disk transport mechanics to run at half speed.
PLUNGE 1/4 SPD	Allows the disk transport mechanics to run at quarter speed.
STARWARS	The display shows 0 0 0. Each “0” indicates one of the paths that the disk transport mechanism follows in front of each stack of optical disks. If the path is clear, a “0” displays; if the path is blocked (because of an optical disk that is not inserted fully into its storage slot for example), an “*” will be displayed. This display is automatically updated if the status changes.

Troubleshooting and Diagnostics
Running an Internal Test

Test Name	Description
BOTTOM THUMB	Reports THUMB A, THUMB B, or NO THUMB. Looks at the top and bottom thumb sensors and reports whether the thumbs on the disk transport mechanism are in the forward or back position. If THUMB A or THUMB B is returned, the specified thumb is the forward position. If NO THUMB is returned, both thumbs are in the back position.
TOP THUMB	Reports ON or OFF. Looks at the top thumb sensor which reports whether or not the thumb that is currently on the top side of the disk transport mechanism is in the forward position. If ON is reported the thumb is in the back position; if OFF is reported the thumb is in the forward position.
TRANSLATE SENSOR	Reports ON or OFF after checking the translate calibration sensor. (Display automatically updates if the status changes.)

Running an Internal Test

Overview

This chapter gives information on the following topics:

- replacing a power supply
- replacing the mailslot assembly
- replacing the control panel assembly
- replacing an optical drive with the jukebox offline
- replacing an optical drive while the jukebox is online
- replacing the interposer PCA
- replacing the picker
- removing and/or replacing the translate frame (including the picker)
- removing and/or replacing the vertical encoder strip
- replacing the vertical motion motor
- replacing the vertical motion motor gear box
- replacing the robotics controller PCA
- replacing the SCSI cable and interface PCA
- downloading firmware
- re-initializing the robotic controller PCA RAM
- replaceable parts

Protecting Yourself and the Product

WARNING

Do not disassemble the optical drive mechanism. The optical drive mechanism becomes a Class 3B laser device when disassembled. If the drive is disassembled, exposure to the invisible laser beam and hazardous invisible laser radiation could result in blindness.

NOTE

An optical drive that has been disassembled will not be accepted as an exchange assembly.

Electrostatic Discharge (ESD) Precautions

The optical disk jukebox contains very sensitive electrical components. It is *extremely important* that you follow the proper procedures for preventing ESD (Electrostatic Discharge). Use wrist-grounding straps, anti-static mats, and anti-static work stations when removing and replacing the major assemblies.

NOTE

Failure to follow proper procedures could lead to intermittent failures and/or premature hard failures in the disk controller and mechanism.

Required Tools

The following tools are needed for assembly/disassembly of the jukebox:

- Pozidriv® magnetized screwdriver
- flatblade screwdriver
- Needle-nose pliers
- Flatblade screwdriver
- Torx® driver with the following bits: T-10, T-15, extended T-15, T-20

Service Access

WARNING

Disconnect the power cord before taking the jukebox apart to prevent possible electrical shock.

CAUTION


Do not switch off power to the jukebox until you are sure the SCSI bus is *inactive*. Switching off the jukebox when the SCSI bus is active can cause data loss and/or indeterminate bus states.

When servicing the jukebox, be sure that disk cartridges are not moved from their original slot locations. If you need to remove the cartridges, record their slot locations and orientation so they can be replaced to their original positions.

Removing the Right, Left, and Rear Access Panels

1. Turn power off and unplug the power cord from the power source.
2. Refer to Figure 5-1 for the location of the mounting screws on the panel you want to remove.
 - the left-side panel does not use any fastening screws
 - the right-side panel has one combination slotted/Torx screw on the bottom edge
 - the rear panel has eight T-20 screws on its perimeter

Figure 5-1 Mounting Screws on the Right, Left, and Rear Access Panels




Removal and Replacement
Service Access

Removing the Left and Right Front Panels

1. Remove the *rear* panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. *If removing the front right panel*, the panel on which the control panel is mounted, refer to Figure 5-2:
 - a. Remove the control panel cover plate (#1).
 - b. Remove the control panel interface cable and power cable from the control panel PCA (#2 and #3).
 - c. Rotate the control panel until the display faces the right end of the jukebox (see #1 on Figure 5-3).


Figure 5-2

Control Panel Cables Disconnected When Removing the Right Front Panel



- Depending on which panel you are removing, remove the T-20 screws labeled #2 on the front and back of the left front panel or the T-20 screws labeled #3 on the front and back of the right front panel. (See Figure 5-3).

Figure 5-3 Left and Right Front Panel Mounting Screws




- Remove the T-20 screw located under the rear edge of the top plastic center cover (#4 on Figure 5-3).
- Pull the top plastic center toward the rear of the unit to unlock the tabs (see #5 on Figure 5-3).
- Remove the panel by lifting the panel up from the rear edge, while spreading the bottom of the panels apart.

Replacing a Power Supply

1. Remove the *rear* access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Remove the power plug from the bottom of the power supply (see #1 on Figure 5-4).
3. Disconnect the cables from the top of the supply (see Figure 5-4).
The 5V/12V supply has four cables (#2); the 24V supply has one cable (#3).
4. Remove the two T-20 screws at the top of the supply (see arrows on top of power supplies in Figure 5-4).
5. Lift the supply up and out.

Figure 5-4 Cables and Mounting Screws on the Power Supplies



Replacing the Mailslot Assembly


1. Remove the *right* front panel (refer to “Removing the Left and Right Front Panels” on page 5-6).
2. Remove the two T-15 mailslot mounting screws from the upper left side of the chassis (see arrows on the left side of Figure 5-5).

These screws are recessed. Use a Torx driver with an extended shaft.

3. Unplug the mailslot cable from the interposer PCA.
4. Slide the mailslot out of the jukebox.

Thread the mailslot cable through the slot as you pull the mailslot out of the chassis (see Figure Figure 5-5).

Figure 5-5 Mailslot Assembly Mounting Screws



Removal and Replacement
Replacing the Mailslot Assembly


Reassembly Notes

Thread the mailslot cable down through the slot on the top of the PCA enclosure while inserting the mailslot into the chassis. After mailslot is installed, connect the mailslot cable to the interposer PCA.

Replacing the Control Panel Assembly

1. Remove the *right front* panel (see “Removing the Right, Left, and Rear Access Panels” on page 5-5 and “Removing the Left and Right Front Panels” on page 5-6).
2. Turn the panel upside down.
3. Remove the four T-10 sheet metal screws from the control PCA retaining ring to detach the control panel PCA from the mounting assembly (see the arrows on Figure 5-6).
4. Remove the control panel.

Figure 5-6 Control Panel Assembly Mounting Screws



Reassembly Notes

When replacing the right front panel back onto the chassis, ensure that the control panel is turned to face the same way as when the panel was removed (see Figure 5-3). The control panel PCA can be damaged if oriented incorrectly.

Replacing an Optical Drive — Jukebox Offline


NOTE

Before replacing a drive, obtain the most current version of the jukebox controller and drive firmware for the model and option of the jukebox you are servicing.

Firmware for all models and options of this jukebox is available for download at:
www.hp.com/isupport/optical/fw/firmware.html.


1. Remove the *right side* panel (see “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Remove the drive cables for the failed drive from the interposer PCA. The cable group for drive 1 is shown on Figure 5-7:
3. Remove the T-20 enclosure mounting screw on the enclosure holding the failed drive. The mounting screws for both drives are shown in Figure 5-7).

Figure 5-7 Removing Drive Cables and Enclosure Mounting Screw



4. Carefully slide the drive enclosure back and out of the chassis. Avoid catching the enclosure on cables connected to the other drive enclosures.
5. Remove the T-10 screws that hold the small cable access panel on the top of the drive enclosure. Remove the panel (see Figure 5-8).


Figure 5-8 Unmounting a Drive From An Enclosure



6. Disconnect the drive cables from the rear of the drive (see Figure 5-9).
 - #2 - drive interface cable
 - #3 - SCSI cable
 - #4 - drive power cable

Removal and Replacement
Replacing an Optical Drive — Jukebox Offline

Figure 5-9 Removing Cables From a Drive




7. Remove the four T-10 screws that hold the drive in the drive enclosure and slide the drive out of the enclosure.
8. *If there is a disk in the drive*, use a disk eject tool to remove the disk from the drive.
 - a. Insert the eject tool (or paper clip) into the disk eject access hole (see Figure 5-10).
 - b. When you feel firm pressure on the tip, push forward. The disk mechanism will eject the disk.

IMPORTANT

Note whether the “A” or “B” side faces up when you remove the disk. The disk must be inserted into the replacement drive with the same orientation.

Figure 5-10

Disk Eject Hole



9. Slide the replacement drive into the enclosure nearly all the way. Leave room to connect the drive cables to the rear of the drive.

10. Connect the drive power cable, SCSI cable, and drive interface cable to the rear of the drive(see Figure 5-9).

While placing the drive interface cable onto the drive, slip the plastic cable guide around the interface cable, remove the adhesive backing, and stick the guide to the rear of the drive as shown in #1 on Figure 5-9.

11. Insert and tighten the four T-10 screws that mount the drive into the enclosure.

12. Remount the cable access panel on top of the enclosure with two T-10 screws (see Figure 5-8)

13. If a disk was removed from the failed drive, replace the disk into the drive in the same orientation.

14. Insert the drive enclosure into the chassis and secure the enclosure with a T-20 screw (see Figure 5-7).

15. Connect all drive cables to the interposer PCA as listed in Figure 5-7.

- #1 - drive encloser fan power
- #2 - drive interface cable
- #3 - SCSI cable
- #4 - drive power cable (two connections)

Replacing an Optical Drive — Jukebox Online


NOTE

Before replacing a drive, obtain the most current version of the jukebox controller and drive firmware for the model and option of the jukebox you are servicing.

Firmware for all models and options of this jukebox is available for download at:
www.hp.com/isgupport/optical/fw/firmware.html.

1. Remove the right side panel (see “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. On the interposer PCA, note which drive shows a blinking status LED. Slide the communication switch to the left for this drive (there is a set of LEDs and switches for each drive — an example is shown by #1 on Figure 5-11).
3. *Slide the communication switch to the left for the other drive in the stack (above or below the failed drive, as the case may be). This prevents inadvertent interference with the good drive during this procedure).*

Figure 5-11 Online Drive Replacement LEDs, Communication Switches, and Drive Cables



4. Remove the two drive power connectors from the interposer PCA (see #2 on Figure 5-11).

5. Remove all other drive cables to the failed drive :
 - #3 - SCSI
 - #4 - drive interface cable
 - #5 - drive fan power cable
6. Remove the T-20 screw holding the drive enclosure to the chassis for the enclosure holding the failed drive.

CAUTION

When removing the drive enclosure from the chassis in the next step, be careful not to damage the cables to the other drive in that stack.

7. Carefully slide the drive enclosure back and out of the chassis. Avoid catching the enclosure on cables connected to the other drive enclosure in the stack.

WARNING


The jukebox is active during an online replacement procedure — the picker may move at any time. Do not extend your hand through the chassis into the interior of the jukebox.

8. *If there is a disk in the drive*, use a disk eject tool to remove the disk from the drive.
 - a. Insert the eject tool (or paper clip) into the disk eject access hole (see Figure 5-12).
 - b. When you feel firm pressure on the tip, push forward. The disk mechanism will eject the disk.

IMPORTANT

Note whether the “A” or “B” side faces up when you remove the disk. The disk must be inserted into the replacement drive with the same orientation.

Figure 5-12 Disk Eject Hole




Removal and Replacement

Replacing an Optical Drive — Jukebox Online


9. Remove the T-10 screws on that hold the small cable access panel on the top of the drive enclosure. Remove the panel (see Figure 5-13).

Figure 5-13 Unmounting a Drive From an Enclosure



10. Disconnect the drive cables from the rear of the drive (see #2, #3, and #4 on Figure 5-14).

Figure 5-14 Disconnecting the Cables



11. Remove the four T-10 screws that hold the drive in the drive enclosure and remove the drive from the enclosure.

CAUTION

To provide proper ground and power sequencing, it is important to power the replacement drive in the next steps through the connections on the interposer PCA.

12. Connect the drive power cable between the replacement drive and the interposer PCA. Connect the cable to the drive power connector that was used by the failed drive.
13. Connect the service SCSI cable between your diagnostic PC and the replacement drive. The service SCSI cable is stored to the left of the intrposer PCA..
14. Apply power to the replacement drive using the following sequence:
 - a. Either press **ENTER** three times if the password is 000-000-000 or have the system administrator enter the password to give you access to the menu level below ADMIN *.
 - b. Press **NEXT** or **PREV** until ONLINE DRIVE REPAIR * displays. Press **ENTER**.
 - c. Press **NEXT** or **PREV** to display DRIVE POWER *. Press **ENTER**.
 - d. Press **NEXT** or **PREV** to display DRV<x> POWER OFF, (where DRV<x> is the number of the drive you are replacing).
 - e. Press **NEXT** to select DRV<x> POWER ON. Press **ENTER**.
15. Download the appropriate firmware into the replacement drive.
16. *If a disk was removed from the failed drive, replace the disk into the drive.*
17. Remove power to the drive using the control panel and the following sequence:
 - a. Press **NEXT** or **PREV** until ONLINE DRIVE REPAIR * displays. Press **ENTER**.
 - b. Press **NEXT** or **PREV** to display DRIVE POWER *. Press **ENTER**.
 - c. Press **NEXT** or **PREV** to display DRV<x> POWER ON, (where DRV<x> is the number of the drive you are replacing).
 - d. Press **NEXT** to select DRV<x> POWER OFF. Press **ENTER**.
18. Remove the drive power and cable and service SCSI cable from the replacement drive. Stow the service SCSI cable.

Reassembly Notes

1. Slide the drive into the drive enclosure and give yourself enough room to connect the drive interface cable, SCSI cable, and drive power cable to the rear of the replacement drive (see Figure 5-14).

Stick a clip on the rear of the replacement drive and thread the drive interface cable into this clip as you mount the cables on the rear of the drive (see #1 Figure 5-14).

2. Mount the replacement drive into the drive enclosure with four T-10 screws (two on each side).
3. Mount the cable access panel onto the top rear of the drive enclosure with two T-10 screws (see Figure 5-13).
4. Insert the drive enclosure into the chassis and secure it with the T-20 screw.
5. Route the SCSI cable, drive interface cable, and drive fan power cables up to the interposer PCA. Connect the cables (see Figure 5-11 #3, #2, and #5).

Connect the drive power cables last, over the SCSI cable (see #2 on Figure 5-11).

6. Slide the communication slide switch over to the right for both drives to signal the jukebox that drive replacement is complete (see #1 on Figure 5-11).

The jukebox applies power to the drives and informs the running application that the drives are ready to go online.

7. Replace the right-side access panel.

Replacing the Interposer PCA


1. Remove the right side panel (see “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Disconnect all cables to the interposer PCA (see Figure 5-15).
3. Remove the eight T-20 screws holding the PCA to the chassis.

IMPORTANT

CHECK TO SEE IF THERE IS A CONFIGURATION MODULE MOUNTED ON THE PCA (#1 ON Figure 5-15).

IF A CONFIGURATION MODULE IS INSTALLED, TRANSFER THE MODULE TO THE REPLACEMENT PCA.


Figure 5-15 Disconnecting Cables and Screws



Replacing the Picker


1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Pull the tab on the end of the picker umbilical cable to disconnect the cable from the bottom of the picker (see Figure 5-16).

Figure 5-16 Picker Umbilical Cable



3. Release the translate cable from the side of the translate frame nearest the front of the jukebox (see Figure 5-17):
 - a. Depress the tension spring (#1) on the side of the translate frame to release the tension on the cable and allow you to pass the cable up through the slotted hole (#2).
 - b. Slide the cable into the pinch slot on the side of the picker (#3). Placing the cable in the pinch slot prevents the cable from unraveling from the central picker hub.

Figure 5-17 Releasing and Stowing the Picker Translate Cable



4. Release the translate cable from the side of the translate frame nearest the rear of the jukebox (see Figure 5-17):
 - a. Remove the spring and slotted plug that holds the translate cable (#4). The cable passes through a hole in the side of the frame and into a slotted plug with a tensioner spring. Remove the spring and slotted plug.
 - b. Slide the cable into the pinch slot on the side of the picker (#5). Placing the cable in the pinch slot prevents the cable from unraveling from the central picker hub.

Removal and Replacement

Replacing the Picker

CAUTION


Raise the translate frame only by pulling on the vertical drive rope (see top arrow in Figure 5-18). The frame can be twisted by pulling it by the sides. A twisted frame may cause various errors in operation.

5. Raise the translate frame and picker up to a convenient working height so that you can access the underside of the picker. Insert a screwdriver into the vertical motor gear box to hold the frame in position. (see Figure 5-18).

Pull the frame up to the desired position, and insert a screwdriver into the hole at the rear of the vertical motor gear box to prevent the frame from descending.

Figure 5-18


Holding the Translate Frame in Position



6. Remove the T-10 sheet metal screw that holds the capture spring down (see Figure 5-19).

Figure 5-19


Releasing the the Picker Capture Bracket



7. Remove the capture spring by pulling it up and out of the unit.
8. Rotate the capture bracket 90 degrees and pull the bracket down and out (see Figure 5-20).

Figure 5-20

Removing the Translate Frame Capture Bracket



Removal and
Replacement


Removal and Replacement

Replacing the Picker

9. Remove the tool you inserted into the rear of the vertical motor gear box and lower the translate frame and picker to the bottom of the jukebox.
10. Tilt up the rear end of the picker and left it out of the frame (see Figure 5-21).

Figure 5-21

Rotating the Picker Assembly Out of the Translate Frame



Removing/Replacing the Translate Frame (Including the Picker)


1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).

CAUTION

Raise the translate frame only by pulling on the vertical drive rope (see the top arrow on Figure 5-22). The frame can be twisted by pulling it by the sides. A twisted frame may cause various errors in operation.


2. Raise the translate frame up approximately midway up and secure it with a screwdriver inserted into the hole on the rear of the vertical motor gear box (see Figure 5-22).

Figure 5-22 Raising the Translate Frame and Holding the Frame in Position



Removal and Replacement
Removing/Replacing the Translate Frame (Including the Picker)

Figure 5-23 Releasing the Lower End of the Vertical Encoder Strip



3. Unhook the encoder strip and hang it out of the way (see Figure 5-23).

Pull down on the bottom of the encoder strip to release the strip from its retaining peg. Once released, the strip will slide up and out of the plastic guide.

WARNING

The edges of the vertical encoder are sharp. Be careful.


CAUTION

Handle the encoder strip with care and **ONLY BY THE SOLID SIDE** (see Figure 5-23). The **CLEAR** side is made up of very fine slits and **CAN BE EASILY DAMAGED**.

4. Remove the “visual locator” bracket on the (front) side of the picker translate frame (see Figure 5-24).


Remove the two T-20 screws holding the bracket and rotate the bracket off.

Figure 5-24 The Visual Locator Bracket



5. Disconnect the umbilical cable on the underside of the translate frame (see Figure 5-25).

Figure 5-25 Disconnecting the Vertical Umbilical Cable From the Translate Frame



Removal and Replacement


Removal and Replacement

Removing/Replacing the Translate Frame (Including the Picker)

6. Remove the tool you inserted into vertical motor gear box and move the translate frame down to the bottom of the jukebox.
7. Remove the three rope tensioners from the frame (#1, #2, and #3 on Figure 5-26).
 - a. Remove two T-25 long screws per tensioner. Start with the tensioner at the rear end of the frame (#1 on Figure 5-26).
 - b. Pull all three rope tensioners free of the translate frame.
 - c. Pull the *rear* tensioner upwards to raise all three tensioners up and out of your way.

Figure 5-26


Removing the Tensioners From the Translate Frame



Removing/Replacing the Translate Frame (Including the Picker)**CAUTION**

In the next step, ensure that the plastic rail guides are not damaged when the translate frame is removed.

8. Rotate the rear of the translate frame up and then remove the frame out to the side (see Figure 5-27).

Figure 5-27**Rotating the Translate Frame Out of the Chassis****Reassembly Notes****IMPORTANT**

Take care to install the translate frame properly

If the frame is not mounted level, errors will be caused that will prevent the library from operating.

The following steps explain proper mounting of the frame.

1. Place the frame back in the chassis. Let it rest on its support points. The rear of the frame rests on a ledge on the vertical motor.

Removal and Replacement


Removing/Replacing the Translate Frame (Including the Picker)

2. Pull the tensioners down so that they are next to their mount points on the sides and rear of the translate frame. Press them into the side of the translate frame.
3. While tightening the mounting screw in a tensioner, push down on the frame at that point to make sure that the translate frame remains on its lower stop while you tighten the mounting screw.
4. Check that the translate frame is mounted level on the cables by centering the picker and pushing the frame down lightly and quickly. If you hear a “click” it means that the frame has slack and needs adjustment.

If adjustment is necessary, remount the frame on the tensioners as described in Step 3 and retest.

Figure 5-28

Remounting the Tensioners on the Translate Frame



Mounting the Vertical Encoder Strip

Move the translate frame up and lock it while reinstalling the encoder strip.

Ensure that the encoder strip passes through the sensor slot on the sensor PCA mounted on the side of the picker frame (see Figure 5-23). The strip may be moved off its mounting peg while you are replacing the translate frame in the chassis.

Removing/Replacing the Vertical Encoder Strip

1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).

WARNING

The edges of the vertical encoder are sharp. Be careful.


CAUTION

Handle the encoder strip with care and ONLY BY THE SOLID SIDE . The CLEAR side is made up of very fine slits and CAN BE EASILY DAMAGED.

2. Release the lower end of the vertical encoder strip (see #1 on Figure 5-29).
3. Unhook the top of the encoder strip from the spring and remove (Figure 5-29).

Figure 5-29

Releasing the Ends of the Vertical Encoder Strip



Removal and Replacement
Replacing the Vertical Motion Motor

Replacing the Vertical Motion Motor

1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Disconnect the two power cables to the vertical motor (see Figure 5-30).


NOTE

Note the orientation of the motor before removing it in the next step. The motor must be replaced in the same position on reassembly.

3. Remove two T-15 motor mounting screws on the gear box. Remove the motor (see Figure 5-30).

Figure 5-30


Cables and Mounting Screws on the Vertical Motion Motor



Replacing the Vertical Motor Gear Box

1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Remove the translate frame (refer to “Removing/Replacing the Translate Frame (Including the Picker)” on page 5-27).
3. Pull the rear tensioner upwards to raise all three tensioners up to a convenient working height .

Figure 5-31 Opening the Tensioners to Relieve Cable Tension




4. Release the tension on the rear rope tensioner (drive rope) using the following steps (see Figure 5-31):
 - a. Pull back the metal section to release the metal securing tab seated in the plastic section.
 - b. Swing the metal section out and off the pivoting pegs on the plastic section.

Removal and Replacement

Replacing the Vertical Motor Gear Box


5. Take the drive rope off the upper pulleys (see #3 on Figure 5-31).
6. Remove the drive rope from the rear tensioner (see #2 on Figure 5-31).
 - a. Unfasten the spring.
 - b. Pull both ends of the rope out of the tensioner.
7. Remove the T-15 screw from the rope coupler cover (see #1 on Figure 5-32).

Figure 5-32 **Disconnecting the Rope Coupler**



8. Remove the drive rope from the coupler (see #2 on Figure 5-32)
9. Remove the drive motor and gear box (see Figure 5-33).
 - a. Remove the T-25 screw from the base of the gear box.
 - b. Tip the gear box forward and lift it out.

Figure 5-33 Vertical Motor Gear Box Mounting Screw



Reassembly Notes

When replacing the rear rope tensioner, be sure that the tensioner spring area is positioned so that it faces you. This ensures that the rope tensioner is in the right position to fasten to the translate frame (see Figure 5-34).

To give yourself enough slack in the , fasten the drive rope ends to the rope tensioner *before* hanging the drive rope over the top two pulleys.

Before applying tension by setting the rope tensioners, insert the ropes into the rope coupler and attach the coupler cover plate (see Figure 5-32).

Removal and Replacement
Replacing the Vertical Motor Gear Box

Figure 5-34

Positioning the Tensioner to Mount on the Translate Frame





Figure 5-35

Placement of the Ropes in the Rope Coupler




Replacing the Controller PCA

1. Remove the rear access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Remove the six T-20 screws on the controller PCA cover (see Figure 5-36).


Note the two reference pin holes on the rear edge of the cover. Use these pins to position the cover correctly during reassembly.

Figure 5-36 Removing the Controller PCA Cover



Removal and Replacement Replacing the Controller PCA

Figure 5-37 Controller PCA Cables and Screws




3. Disconnect the following cables from the controller PCA (see Figure 5-36):
 - SCSI cable (#1)
 - Power cable (#2)
 - Motor encoder and power cables (#3)
 - Picker cable (#4)
4. Remove the seven T-20 screws from the controller PCA and remove the PCA.

Replacing the Interface PCA

1. Remove the left access panel (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).
2. Remove the four T-20 screws holding the interface module cover (see Figure 5-39).


Figure 5-38 Removing the SCSI Interface Module



Removal and Replacement
Replacing the Interface PCA

3. Disconnect the cables to the interface PCA (see Figure 5-40).

Figure 5-39 Removing the SCSI Interface PCA




4. Remove the six T-15 PCA screws and remove the PCA (see Figure 5-39).

5. When reassembling put the cables on the interface PCA as follows:
- #1 - SCSI cable
 - #2 - interface PCA power cable
 - #4 - GPIO cable

Figure 5-40

Cables on the Interface PCA



Replacing the SCSI Cable

1. Remove the right and rear access panels (refer to “Removing the Right, Left, and Rear Access Panels” on page 5-5).

2. Remove the SCSI cable from the interface PCA.

Do *Steps 2 and 3* of “Replacing the Interface PCA” on page 5-41. Remove only the SCSI cable on the bottom of the interface PCA.

3. Remove the SCSI cable from the controller PCA.

Do *Steps 2 to 4* of “Replacing the Controller PCA” on page 5-39 to remove the controller PCA. Remove the SCSI cable from underneath the controller PCA.

Checking the RFI Adjustments

NOTE

The following RFI adjustments must be maintained after servicing the jukebox.

Depending on the service performed, these configurations may be altered. The purpose of this section is to remind you of the RFI adjustments that must remain in place.


Be sure that there is an RFI clamp holding the SCSI and GPIO cable together as shown in Figure 5-41. (Clamp (#1) has end clips (#2) to hold the two plates together.

Be sure that there are cable clamps holding the SCSI and GPIO cables to the side of the jukebox as shown in Figure 5-42.

Be sure that there is an EMI strip installed on the right-side panel as shown in Figure 5-43.

Figure 5-41

RFI Clamp on the GPIO and SCSI Cables



Removal and Replacement
Checking the RFI Adjustments

Figure 5-42

Cable Clamps on the GPIO and SCSI Cables





Figure 5-43

EMI Strip on the Right-Side Panel



Upgrading Firmware to the Current Revision Level

What is Needed

PC Tool hardware

The following hardware and software is required:

- IBM AT-compatible computer
- Adaptec interface board
- Cables and adapters that will enable you to connect the SCSI port of your PC tool to a high-density SCSI port on the jukebox.

In addition to a service SCSI cable stored inside the jukebox you may need an adapter from the list below:

PTI cable: 50-pin to 68-pin cable (PTI part number HP01)

Adaptec products Adaptec APA 1460 connector
(Adaptec part no. ACK-1460-50HD)

Internal converter
(Adaptec part no. ACK-68P-50P-IU)

Standard 68-pin male to 68-pin male SCSI cable

- A firmware download utility
- An MO scratch disk for testing the drives.

SCSI PRO®

CoComp

www.cocomp.com

SCSI Toolbox®

Peripheral Test Instruments (PTI)

www.pti.com

Upgrading Firmware to the Current Revision Level

Current Jukebox and Drive Firmware

Obtain the most current version of the jukebox controller and drive firmware for the model and option of the jukebox you are upgrading/converting.

Firmware for all models and options of this jukebox is available for download at:

www.hp.com/isgupport/optical/fw/firmware.html.

Tools

- T-10 and T-20 Torx® drivers

Check the Firmware Revision Level

1. Ensure the jukebox is powered on.
2. Press **NEXT** to select **INFO ***, then press **ENTER**.
3. **REVISION #** displays. Press **ENTER** to view the robotics controller firmware revision.
4. Write down the revision number, then press **CANCEL**.
5. Press **NEXT** until **DRIVE FW *** displays, then press **ENTER**.
UPDATING displays briefly, then **Dx REV zzzz** displays (where x represents a drive number and z represents the revision level of that drive).
6. Press **NEXT** or **PREV** to select other drives and press **ENTER**.
7. After viewing the revision level for all drives, press **CANCEL**.
8. Determine if the jukebox and/or drives have the current firmware revision level.
 - If the firmware is current, no download is necessary.
 - If the jukebox controller and/or drive firmware is not the latest, go to the next section, "Download Firmware as Necessary."

Download Firmware as Necessary

NOTE

Ensure that the jukebox is not in LUN mode. Downloads must be done in basic SCSI addressing mode (LUN mode off).

IMPORTANT

*If you are going to download firmware for the jukebox controller, the customer's default configurations should be recorded so that the jukebox can be correctly restored. Go to the CONF * menu on the control panel to access and display the current jukebox configurations.*

1. Turn the jukebox off.
2. Ensure that your PC tool is off.
3. Remove any cable connections to the single-ended ports on the interface module.

NOTE

A service SCSI cable is stowed to the left of the drives. This cable is provided in case you need it in the next step.

4. Connect a SCSI cable between your PC tool and one of the single-ended ports on the interface module. (Connectors on the module are high-density.)

Place the interface select switch to the "single-ended" position, if necessary.

5. Turn the jukebox on.

Wait until the jukebox shows `READY` in the display.

6. Turn your PC tool on.
7. Follow your download utilities instructions to download the firmware needed (jukebox and/or drives).
8. Verify the operation of the drives by running a "random write" for approximately two minutes using your PC tool.
9. Verify the operation of the jukebox by running the "Wellness Test" from the control panel.
10. Turn off the PC tool and the jukebox.
11. Remove PC tool SCSI cable from the jukebox interface module.
12. Reconnect the customer's cable to the single-ended port (if that was the configuration).

Reset the interface select switch to differential, if necessary.

13. If you downloaded jukebox controller firmware, go to the CONF * menu and reset any customer configuration that is not default. The default configurations are as follows:

Removal and Replacement
Upgrading Firmware to the Current Revision Level

Table 5-1

Default Configuration Settings

Configuration	Default Value
RECOVERY	ON
DUAL PICKER	ON
STARWARS	ON
SCSI LOG	OFF
SECURE	OFF
SECURE MAIL	OUT
POWER SECURE	OFF
REP RECOVERED	ON
CONF 40	OFF
WRITE VERIFY	ON
LUN Mode	OFF
SCSI Addresses	robotics controller = 6 drive 1 = 5 drive 2 = 4 drive 3 = 3 (if installed) drive 4 = 2 (if installed)
Password	000-000-000

Replaceable Parts

NOTE

The “x” in the part numbers listed in the following parts tables represents a number from “0” to “9” depending on the revision of the part. For example, if the part is newly released, the number will be “0”. The first time the part is revised, the number increments to “1”; the second time the part is revised, the number increments to “2”, and so on.

If you are unsure of the current part number, enter a “0” or a “1” in place of the “x” when checking your parts database and the current part number will display.

Table 5-2 Exchange Parts

FRU No.	Part Number	Description
2	C1113-69x08	optical drive mechanism
19	C1170-69x03	configuration module

Table 5-3 Non-Exchange Assemblies

FRU No.	Part Number	Description
1	C1153-60x01	robotic controller PCA
2	C1113-60x08	optical drive mechanism
4	C1150-60x04	interposer PCA
8	C1150-60x08	SCSI interface PCA
19	C1170-60x03	configuration module
22	C1160-60x22	display assembly
23	C1160-60x23	vertical motor gearbox assembly
24	C1160-60x24	vertical motion motor
25	C1160-60x25	idler pulley kit
26	C1100-60x26	magazine (pair) 8-slots
27	C1160-60x27	dual-cartridge picker

Removal and Replacement
Replaceable Parts

FRU No.	Part Number	Description
29	C1100-60x29	mailslot assembly
30	C1160-60x30	encoder strip
31	C1160-60x26	magazine (pair) 6-slots
32	C1160-60x28	power supply (200w, 5/12v)
33	C1160-60x33	power supply (120w, 24v)
34	C1160-60x34	slave rope
35	C1160-60x35	translate rope
36	C1160-60x36	coupler assembly
37	C1160-60x37	tensioner assembly
39	C1160-60x39	encoder mount
40	C1160-60x40	translate frame
41	C1160-60x41	vertical umbilical cable
42	C1160-60x42	mount guide - slider
43	C1160-60x43	translate umbilical cable
45	C1170-60x59	Internal SCSI Cable
46	C1160-60x46	capture roller assembly
47	C1170-60x47	drive enclosure
48	C1160-60x48	fan
51	C1160-60x51	main power harness
54	C1170-60x54	drive power cable
57	C1160-60x57	vertical path-clear sensor cable
59	C1173-60x59	drive SCSI cable
62	C1170-60x62	drive I/Ocable
65	C1160-60x65	control panel cable


Removal and Replacement
Replaceable Parts

FRU No.	Part Number	Description
66	C1170-60x66	GPIO Cable
78	C1160-60x78	cover window
80	C1160-60x80	right panel standby power switch cable
86	C1160-60x86	AC switch PCA
A	C5175-00202	panel - left side, flint grey
A	C5175-00203	panel - left side, parchment white
B	C5175-00204	panel - right side, flint grey
B	C5175-00205	panel - right side, parchment white
C	C1160-60094	panel - left front, flint grey
C	C1160-60093	panel - left front, parchment white
D	C1160-60095	panel - right front, flint grey
D	C1160-60096	right front panel , parchment white
E	C1160-60084	panel - top right corner, flint grey
E	C1160-60088	panel - top right corner, parchment white
F	C1160-60090	panel - top left corner, flint grey
F	C1160-60091	panel - top left corner, parchment white
G	C1160-00210	panel - rear, flint grey
G	C1160-00211	panel - rear, parchment white
H	C1160-00606	panel - top, RFI
I	C1160-00607	panel -side, RFI
J	C1160-00608	cover, corner
K	C1160-00617	cover, bottom center, flint grey
K	C1160-00618	cover, bottom center, parchment white
	C1160-60199	packaging kit (for reshipment)

Removal and Replacement
Replaceable Parts

FRU No.	Part Number	Description
	9170-1736	ferrite 1/2 width (2 required)
	1400-0514	flat RFI cable clamp
	C1160-80602	EMI gasket

Figure 5-44 Exploded View (1 of 3)



Removal and
Replacement

Removal and Replacement
Replaceable Parts

Figure 5-45

Exploded View (2 of 3)





Figure 5-46 Exploded View (3 of 3)



Removal and
Replacement

Removal and Replacement
Replaceable Parts

Figure 5-47 Power Cabling





Figure 5-48 Rope and Pulley System



Removal and
Replacement

Removal and Replacement
Replaceable Parts

Overview

This chapter gives information in the following topics:

- jukebox robotics
- robotics controller PCA
- interposer PCA
- configuration module
- power supplies
- the SCSI interface on this jukebox
- SCSI interface PCA
- picker
- optical drive mechanism

Jukebox Robotics


Movements

The mechanism code of the jukebox accepts high-level SCSI commands from the interface, translates these commands into servo code for the jukebox, executes the command, and reports status.

When a SCSI command is received, it is translated into a series of smaller submoves in the servo code of the jukebox and executed.

Figure 6-1

SCSI Command Translations



The commands are translated into the following macro-moves, which are basic jukebox functions:

- Move carriage: Positions the picker transport to a position along the rails.
- Flip: Rotates the picker.
- Cartridge I/O: Plunges and retrieves the picker finger assembly to move cartridges between the picker and magazines, drives, or the mailslot.
- Rotate mailslot: Plunges and retrieves the picker finger assembly/leadscrew nut to rotate the mailslot assembly toward and away from the user.

Macro-moves consist of one or more combinations of position or saturation type micro-moves.

There are two types of micro-moves:

- Position move: Moves the driving motors a given distance at peak speed and is used for high-speed, unobstructed movements of known distances.
- Saturation move: Same as a position move except that a high force is expected within a given distance; however, motion is halted if force exceeds a specified threshold. These moves are used for low-speed unobstructed movements that are adaptable.

Each micro-move within a specific macro-move has a unique set of stability, performance, error recovery, force, and reliability criteria. Therefore, each micro-move is assigned a unique identification code (ID), which is used to determine how the move should be performed.

The Robotics Controller PCA

The robotics controller PCA contains the following major components, which are illustrated in Figure 6-2 on page 5-6:

- **Microprocessor:** The MICROPROCESSOR is a Motorola MC68EC000 running at 12.288 MHz. This microprocessor controls all processes on the controller PCA such as servos, SCSI interface, and commands to the control panel. Associated with the microprocessor is clocking circuitry, RAM with standby power supplied by a capacitor, and ROM.
- **Jukebox ASIC:** The JUKEBOX APPLICATION-SPECIFIC INTEGRATED CIRCUIT (ASIC) provides an interface to the processor interface, programmable features, and a servo system. The ASIC is also the interface between the processor and the motors. The ASIC reads the position encoders and uses that information to increment or decrement counters on the chip. The ASIC also provides pulse width modulation (PWM) output signals to drive the motor circuitry.
- **SPIFI Chip (SCSI bus control):** The processor interface function of the chip includes the handling of internally- and externally-generated interrupt sources


The programmable features section of the chip provides a control panel display state machine and firmware-configurable feature and general-purpose ports.

The servo system section of the chip provides servo timers, three motor control pulse-width modulators, and three quadrature encoder channels.
- **Flash EEPROM:** FLASH EEPROM. The controller firmware resides in two flash EEPROMs. These flash EEPROMs allow new firmware versions to be downloaded to the controller in the field.
- **RAM:** RAM. The two RAM chips are special, low-power CMOS static RAMs. A standby capacitor on the PCA takes over powering these chips if main power is lost. The chips remain in standby mode (from about 10 to 60 days), providing a non-volatile memory storage capability when the unit is powered off.
- **Front panel control and filament drive:** The control panel drivers generate a vacuum filament display using a 7.5-volt supply tied to a 5-volt reference, which results in an excitation voltage of from two to three volts. The grids of the display are at approximately 20 volts. Buffers for incoming control panel switch signals and signals from the mailslot sensor are also handled by the control panel drivers.

Theory of Operation
The Robotics Controller PCA

Figure 6-2


Robotic Controller PCA Block Diagram



Interposer PCA

The interposer PCA is an extension of the controller PCA.

Figure 6-3 Interposer PCA Block Diagram



Theory of Operation

Interposer PCA

(Use the top portion of the diagram for the following explanation.)

The single, GPIO and power connection from the controller PCA is J20. Address decode and data buffering takes addresses from the controller PCA and sends the data to proper locations and takes received data and routes the data to the proper destination.

Ground, 5 V, and 12V are supplied to the optical drives directly through their own power circuitry on the interposer PCA (see the top of the diagram). The controller can control power application to the drives through this circuitry. In the event of a drive failure, the controller sets the displays of the online drive repair LEDs.

Power to the drives can also be removed by unplugging the J19, J18, J8, and J6 connectors. These connectors are the four-pin connectors on the drive power cables and act like power on/off switches. Power to the drives is supplied through the eight-pin connectors J26, J25, J16, and J15.

The controller communicates to the drives through each drive's "AC interface connector." Status signals and commands available include: requesting a drive eject, spin-down requests, drive sensing, error status detection, sensing presence of a cartridge, resetting the drive, sensing a loaded cartridge, setting write with verify, and setting the SCSI ID for the drive.

The controller can talk (serial protocol) to each drive individually through the serial port multiplexer (MUX). This communication path, which is also routed through the "AC interface connector," enables the controller to request the drive's serial number and revision of firmware being used. The controller can also use the serial MUX to directly talk to the configuration module.

The vertical-clear-path emitter drivers on the interposer PCA output to the emitters in the vertical-path-clear LEDs through connector J4.

J3 receives mailslot information and front panel key strokes. The controller can read key strokes through the J3 connection, but the controller sends front panel display information directly to J2.

(Use the bottom portion of the diagram for the following explanation.)

J1 is the SCSI input from the host computer. The input is directly bused to connectors J24, J23, J14, and J13, which are the connections to drives 1, 2, 3, and 4 respectively. The bus uses 48 of the 50 pins of the SCSI bus.

SCSI is *totally separate* from any other electronics on the interposer PCA except for two signals, Req and Ack. The Ack signal comes from the host computer, is buffered on the interposer PCA, and sent to each drive individually. Req signals come from the drives and are buffered into *one* signal going back to the host computer. If a

drive problem occurs, there is a possibility that this problem could be from the interposer's buffering of the Req and Ack signals. But if the problem is due to Req and Ack, it will probably affect only *one* drive.

Configuration Module

The configuration module is a “key” that enables activation of the full complement of slots in the jukebox.

The module is plugged into a connector on the interposer PCA (see #1 on Figure 5-15).

All jukeboxes are shipped with a full complement of slots installed. The jukebox may however be sold and used as a “half” version using 32 slots. When a configuration module is plugged into the interposer PCA, and power is turned on, the jukebox will sense the additional 32 slots and automatically begin operating as a full, 64-slot jukebox.

This presence of this module is confirmed regularly by the jukebox firmware. If the module is removed, the jukebox will fail. When restarted, the jukebox will once again operate in the “half” mode.


Power Supplies

There are two autoranging power supplies.

- One supplies +5 volts at 15 amperes and +12 volts at 10 amperes, which powers the drives and the jukebox logic.
- The other supply provides +24 volts at 5 amperes, which powers the motors.

Figure 6-4

Power Supplies and Poweron Sequence



Line power is connected through the power distribution PCA in the interface enclosure. Connection is direct to the 24-volt power supply. When the 24-volt power supply comes up and is good AND if the power standby switch on the right side of the jukebox is in the ON position, the output of the 24-volt power supply is enabled. The 24-volt output closes the relay on the power distribution PCA, allowing line power to be applied to the 5/12-volt power supply for the jukebox.

The 24V power supply is equipped with a fan-detect circuit that turns the supply off if the fans over the drives stop operating.


SCSI Interface PCA

The SCSI interface PCA has two major functions:

- Logically connect the active host SCSI bus (single-ended or differential) to the internal single-ended SCSI device bus.
- Operate in a LUN mapping mode.

Internally, the jukebox has a single-ended SCSI bus. The external differential and single-ended connections are on the top of the PCA and the single-ended bus connection to the jukebox is on the bottom. A slider switch between the two external connectors on the top of the PCA selects which type of input will be accepted. See Figure 6-5.

Figure 6-5 SCSI Interface PCA Block Diagram




Theory of Operation

SCSI Interface PCA

Figure 6-6

SCSI Interface PCA



The jukebox communicates to the PCA through a GPIO bus.

The differential and single-ended connectors are on the top of the PCA and the single-ended bus connection to the jukebox is on the bottom. A slider switch between the two external connectors selects which type of input will be accepted.

Four jumpers select the configuration for termination alternatives

- J6 - enable/disable differential host TERMPPOWER. PIN 1 and 2 jumpered together allows the PCA to provide TERMPPOWER to the differential external [host] SCSI bus (default).
- J5 - enable/disable internal bus TERMPPOWER. PINS 1 and 2 jumpered together allows the PCA to provide TERMPPOWER to the internal SCSI bus (default).
- J4 - bus terminator configuration. PIN 1 and 2 jumpered together enable bus termination (default). When enabled, active termination is supplied for the internal bus at this PCA; termination at the other end of the SCSI cable is by a clamp terminator attached to the SCSI cable near the last drive connection.
- J1 - enable/disable single-ended host TERMPPOWER. PIN 1 and 2 jumpered together allows the PCA to provide TERMPPOWER to the single-ended external [host] bus (default).

The two large components on the PCA are the Field-Programmable Gate Array and the microprocessor. The microprocessor is an 80C52 that has flash-programmable memory on board. (There are no boot ROMs on this PCA).

After the jukebox runs its selftest on wakeup, it instructs the PCA to come up in whichever mode has been selected by the user. It can come up either as a repeater or in LUN mode. Communication from the robotic controller is through the GPIO bus cable. (If the GPIO cable is not connected at startup, the PCA will come up as a repeater.)

A “heartbeat” LED is located on the bottom edge of the board. This LED will continuously flash at a slow rate when power is applied. If the LED is either on steady or off, this indicates a problem with the PCA.

An LED, visible through the top of the interface enclosure, is mounted between the interface connectors on each side. These LEDs light to show which interface has been selected. If the wrong interface type is connected to the interface connector on this PCA, the LED will continuously and rapidly flash to alert the user to this error. No damage is caused to the chips on the PCA by having connectors in the wrong position.

During powerup, the position of the interface selector switch is checked to see which external bus is active and if the proper bus type is on the selected interface port.

If the differential bus is active, the DIFFSENSE signal on the SCSI bus is checked. If this signal is LOW, it means that a single-ended bus has erroneously been connected to the differential connector. The bus is immediately made inactive to protect the chips.

In addition to checking the position of the interface select switch on powerup, the controller is informed of any change to this switch during normal operation. If the switch position is changed, a BUS RESET signal is sent to the robotics controller on the internal SCSI bus

NOTE

It is important to provide proper termination on whichever external SCSI bus (single-ended or differential) that is in use. If the SCSI bus is not being daisy-chained to another peripheral (and terminated there) then termination must be provided at this PCA.

Configuring This Jukebox on a SCSI Bus


This jukebox is a “fast and narrow” SCSI device with the capability to connect to either a narrow single-ended bus or a wide differential bus.

In the diagram below, note that the single-ended (50-line) bus is brought directly onto the jukebox internal narrow bus. The differential interface accepts a wide bus in its 68-pin connector, but only *uses the 50 data and control lines* that comprise the “narrow” portion of the bus. The other 18 lines that provide the upper IDs and data of the wide bus are ignored. Note that all lines of the wide bus pass through the two 68-pin differential connectors. The wide bus is maintained as a wide bus.

The *single-ended* connectors are 50-pin and can accept only a narrow bus. The *differential* ports use 68-pin connectors and can accept (and pass through) a wide bus.

Figure 6-7

Single-ended and Differential Interfaces on This Jukebox



Adding Devices to the Bus

When considering adding other devices to the jukebox bus, consider the following:

- Will adding a device onto a bus with this jukebox interfere or degrade the performance of the jukebox or the device that is added?
- If the decision is made to add other devices to the jukebox bus, what SCSI requirements must be observed to make sure the bus will work?

The recommended configuration of this jukebox is as the only device on a bus. The recommendation is the same whether the bus is single-ended or differential. One reason for the recommendation is that interactions on a SCSI bus can be complicated. The more devices on the bus, the more chance for problems. Another reason is that this jukebox, when fully utilized, is capable of using up the full bandwidth of the bus. Performance of one or all of the devices on the bus can be affected.

Consider the quantity of data that the bus will have to carry, the frequency of data transfer, and the priority of the data transfer under consideration. If the jukebox is used as a backup or archive device, the demands on the jukebox will be different than if the jukebox is used for near-online storage where requests for data are more random in both frequency and amount. If the jukebox will be used at the same time as the other device, or devices, you should expect a drop in performance.

Mixing Wide and Narrow Devices


Try to cable systems so that you do NOT mix wide and narrow buses.

Connecting devices of the same bus width, such as all narrow (50-pin) is a simple process of daisy-chaining the devices, and terminating both ends of the bus. However, mixing narrow and wide devices invites problems.

Theory of Operation

Configuring This Jukebox on a SCSI Bus


This method should only be implemented by an experienced systems integrator who is highly knowledgeable about SCSI. Since the wide (68-pin) buses need more data lines on the bus for their data transfer, it's necessary that the cables connecting the devices are 68 pin. The data would be lost if the devices were set up as depicted in the figure below.



Because a narrow device only has a 50-pin connector, it will not transmit the eight extra bits of data needed for the wide device on the end of the bus. Using only 50 lines also prevents the narrow device from passing along the IDs of devices at 8 or above.

The lower eight data lines transfer commands and messages, allowing all devices, regardless of size, to co-exist on the bus. However, data transfers and device addressing occur on the higher bits. Since a narrow device can't "see" the upper 8 data bits, that translates to it not being able to "see" wide devices with a SCSI ID above 8. The host adapter is a device, so if mixing wide and narrow devices on the bus, the host adapter must be at an ID that all devices can address.

If mixing narrow and wide devices is unavoidable, use the configuration described on the next page.



It is very important that the 68-pin to 50-pin cable is properly configured to assure that the eighteen truncated lines are properly terminated.

Cable Lengths

Observe SCSI cable maximum lengths;

- 3 meters (9.8 feet) for the single-ended bus (remember, this is a fast device)
- 25 meters (82 feet) for the differential bus.

Termination

- Refer to the documentation for the particular adapter being used to see how to apply termination.
- Use active terminators to reduce noise sensitivity.
- Never terminate the bus at any place except the physical ends. Terminating the bus in the middle will probably cause the bus to become inoperable or operate in a state that could cause data loss.
- If devices are on both sides of the host computer adapter (such as hard drives internal to the host computer and a jukebox external to the host computer) make sure that there is no termination on the host computer adapter. Termination must be only on the device inside the computer that is farthest from the host adapter (on the bus) and the last physical device on the bus external to the computer.

Configuring This Jukebox on a SCSI Bus

General

- Do not connect a single-ended bus to a differential bus. Damage can occur.

NOTE

For current information on issues relating to installation, operation, and support of jukeboxes, refer to:

HP Optical Storage

www.hp.com/isgsupport/optical/index.html

Picker

The picker in this jukebox is capable of holding two disk cartridges at once. Its two thumbs can be addressed in two ways:

- Address the picker in single-picker mode,
- Address the picker in dual-picker mode.

Single-picker Mode

In single-picker mode, the picker is addressed as a single element number. Since the driver cannot address each thumb individually, the firmware makes the best choice for which thumb to use.

SCSI commands, such as Read Element Status and Mode Sense, report back a single element address for the transport element. In this jukebox, the single element address is 0.

Dual-picker Mode

In dual-picker mode, each thumb on the picker is considered an element and is addressed individually by its own element number, 16 or 17.


Even though it is in dual-picker mode, the picker can also be addressed as a single element when the translate assembly is executing Exchange, Move and Position to Element commands. The translate assembly may be given the single element numbers of 0 (default), 16 or 17.

When moving cartridges where the source or destination element is the picker, each thumb must be addressed. One thumb is at element address 16 and the other thumb is at element address 17. The SCSI commands, such as Read Element Status and Mode Sense report back the two element addresses for the transport element.

Optical Drive Mechanism

Figure 6-8 provides an overview of the optical drive mechanism.

Figure 6-8 **Optical Drive Functional Diagram**



Controller

The controller is a highly-specialized integrated circuit that handles SCSI control, data buffering, and encode/decode.

The data buffer function provides a buffer to match transfers to and from the host computer and the optical disk. The data buffer provides a cache for read and write operations, optimizing the speed of these transfers.

This controller provides the SCSI interface connection to the host computer that consists of the electrical signals and the firmware, which decodes the various commands and messages on the SCSI bus and instructs the drive to take appropriate action.

The encode/decode function encodes and decodes data for read and write transfers. During a write function, user data is sent via the SCSI bus. The encoder converts the parallel data into an encoded serial bit stream that includes all the format and error correction features required to meet the ANSI and ISO specifications. During reads, the decoder converts the serial data stream, which includes format and error correction features, into parallel data.

Central Processing Unit (CPU)

The central processing unit for all drive functions includes the loading motor.

Gate Array

This component contains circuitry to interconnect the major blocks (CPU, DSP, write/read channel).

DSP (Digital Signal Processor)

The DSP controls the following servos: spindle motor/speed, laser power control, track following, seek/position maintenance, focus actuation, fine position actuation, and coarse position actuation. Whenever the drive is performing a read or write operation, all these servos are activated.

Read / Write Channel Electronics

Read/write channel electronics take analog data from the optical head and convert it into digital "transitions." These transitions are decoded by the encoder/decoder electronics in the controller chip to extract data from format and error correction features. The write channel electronics take the serial data stream from the encoder/decoder and convert the digital pulses into analog data. This analog data is then sent to the optical head.

Loading Motor

The loading motor loads and unloads the optical disk cartridge. The loader motor includes a gear train and rack-and-pinion system that allow the cartridge shuttle to raise and lower the cartridge within the loader housing.

Bias Magnet

The bias magnet subassembly sits on top of the cartridge shuttle and provides the correct polarity for erasing or writing data.

Optical Head

The optical head assembly contains both mechanical and electronic components and is a “split optics” design, which physically separates the laser diode.

The actuators and laser diode (and associated detectors) are on a small PCA on the optical head assembly. The main components are as follows:

- Auto Laser Power Control (ALPC): Controls the intensity and duration of the laser beam for erase, write, and read operations.
- Focus Servo (Fcs): Controls the vertical motion of the objective lens to focus the laser beam on the disk surface.
- Fine Tracking Servo (Trk): Controls the horizontal motion of the objective lens to follow the track of the disk.
- Linear Motor (LM): Positions the actuator in the vicinity of the desired track on the disk.

Errors

The various error thresholds are the basis for deciding whether or not to spare a sector. This could happen during the certification process (i.e. the slip sparing algorithm) or auto-reallocation during a SCSI Write command (i.e. the replacement sparing algorithm). These error thresholds are related to the format of a sector in the User Zone.

Each sector in the User Zone consists of the following:

- Header
- User data
- Parity bytes for error correction

Each header consists of three copies of the sector's track number, sector number, and a Cyclic Redundancy Check (CRC). The error threshold is determined by the number of sectors found “good.”

The other error threshold of interest pertains to the degree of error correction required on the data. The error correction code (ECC) used causes parity bytes to be written following the user data. During a data recovery operation, these bytes are used to detect and correct up to 8 defective bytes in an interleave. Each sector has 10 (5) interleaves with 120 (122) bytes in each interleave. The actual number of bytes per interleave requiring correction is used as an error threshold. Consult the ISO standard for more details.

The table on the next page shows the error thresholds for the optical drive. The sector IDs column refers to the minimum number of sector IDs that must be read correctly for the corresponding operation to be deemed successful. The ECC level column refers to the to the maximum number of bytes per interleave that require correction in order for the corresponding operation to be deemed successful.

Theory of Operation
Optical Drive Mechanism

Operation	Sector IDs	ECC Level
Format	1	3
Write	2	-
Erase	2	-
Verify	2	4
Read (recovered)	1	7
Read	1	8

Error Detection

The jukebox error detection methods are extensive. Both processes and sensors detect errors.

Each of the processes that detect errors are interrelated. Depending on the error condition, the jukebox expects feedback from one or more of the following processes before a diagnosis is made:

- **Overforce shutdown:** An overforce shutdown occurs when the motors exert more force than is expected or required. If this occurs, the servo automatically shuts itself down to prevent parts damage. After an overforce shutdown occurs, the jukebox analyzes the situation, self-calibrates, and attempts a retry
- **Sense of touch:** Sense of touch is the process where actual force used is compared to the recommended force for each move. The jukebox uses this information to detect errors or qualify moves. The difference between sense of touch and overforce shutdown is that the servo is not automatically shut down if sense of touch detects an error.
- **Motor position:** The positions of the motors are continuously monitored by the controller PCA. The position, along with the sense of touch feedback, is a valuable source of error detection.

A **Safety and Regulatory Information**

Overview of this Appendix

This appendix contains important safety and regulatory information for the United States, Finland, Sweden, Germany, United Kingdom, European Union, and Japan.

CDRH Regulations (USA Only)

The Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration implemented regulations for laser products on August 2, 1976. These regulations apply to laser products manufactured from August 1, 1976. Compliance is mandatory for products marketed in the United States. The labels and artwork shown below indicate compliance with CDRH regulations and must be attached to laser products marketed in the United States.

WARNING

Use of controls, adjustments or performing procedures other than those specified in this manual may result in hazardous laser radiation exposure.

NOTE

Complies with 21 CFR Chapter 1 Subchapter J.

Laser Class Information: A black on yellow label which reads, "Class 1 Laser Product" printed in English, French, German, Finnish, Japanese, and Spanish.

United Kingdom Telecommunications Act 1984

The HP SureStore Optical 160ex, 320ex and 400ex jukeboxes are approved under Approval Number NS/G/1234/J/100003 for indirect connection to Public Telecommunication Systems within the United Kingdom.

Declaration of Conformity

according to ISO/IEC Guide 22 and EN 45014

Manufacturer's Name: Hewlett-Packard Co.
Manufacturer's Address: Storage Systems Division
700 71st Avenue
Greeley, CO 80634 USA

declares, that the product

Product Name: Optical Disk Library
Model Numbers: C115x, C116x, and C117x (all W or W/O suffixes)
(x is 0, 2, or 3)
Product Options: All Options

conforms to the following Product Specifications:

Safety: EN 60950: 1992+A1+A2:1993+A3:1995/IEC950(1991)+A1+A2+A3
EN 60825-1 (1994) / IEC825-1 (1993), Laser Class 1
EMC: EN 55022 (1994) / CISPR 22 (1993), Class A
EN 50082-1 (1992)
prEN 55024-2 (1992) / IEC 1000-4-2 (1995), 4 kV CD, 8 kV AD
prEN 55024-3 (1991) / IEC 1000-4-3 (1995), 3 V/m
prEN 55024-4 (1993) / IEC 801-4-4 (1988), 1 kV Peak Power Lines
0,5 kV Signal Lines
EN 61000-3-2 (1995) / IEC 1000-3-2 (1995), Harmonics
EN 61000-3-3 (1995) / IEC 1000-3-3 (1994), Flicker

Supplementary Information:

The product herewith complies with the requirements of the following Directives and carries the CE marking accordingly:
the EMC Directive 89/336/EEC -the Low Voltage Directive 73/23/EEC (including 93/68EEC)

The Manufacturer listed above declares that this product has been tested and found to comply with the limits of a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
a) Reorient or relocate the receiving antenna. b) Increase the separation between the equipment and receiver, c) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, or d) Consult the dealer or an experienced radio/TV technician for help.

Change or modification of this equipment not expressly approved by Hewlett-Packard could void the user's authority to operate this equipment. Only use the cables, connectors, power cords, and accessories supplied with this equipment or expressly approved by Hewlett-Packard.

Storage Systems Division March, 1998 Greeley, Colorado, USA

For Regulatory Compliance Information ONLY, contact:

Australian: Product Regulations Manager, Hewlett-Packard, Australia Ltd., 31-41 Joseph Street, Blackburn, Victoria 3130, Australia
European: Your local Hewlett-Packard Sales and Service Office or Hewlett-Packard GmbH, Department TRE, Herrenberger Strasse 130, D-71304 Boblingen (FAX:+49-7031-14 3143)
USA: Product Regulations Manager, Hewlett-Packard Company, 700 71st Avenue, Greeley, CO 80634 USA, (Phone: 970-350-5600).

Herstellerbescheinigung

Diese Information steht im Zusammenhang mit den Anforderungen der Maschinenlärn information sverordnung vom 18 Januar 1991.

Schalldruckpegel $L_p < 70$ dB(A)

- am arbeitsplatz
- normaler betrieb
- nach ISO 7779:1988/EN 27779:1991 (Typprüfung)

English Translation of German Sound Emission Directive

This statement is provided to comply with the requirements of the German Sound Emission Directive, from 18 January 1991.

Sound pressure $L_p < 70$ dB(A)

- at operator position
- normal operation
- according to ISO 7779: 1988/EN 27779: 1991 (type test)

Turvallisuusyhteenveto

Laserturvallisuus

LUOKAN 1 LASERLAITE

KLASS 1 LASER APPARAT

HP SureStore Optical 160ex, 320ex, 400ex optiset levymuistiasemat ovat käyttäjän kannalta turvallisia luokan 1 laserlaitteita. Normaalisissa käytössä levymuistiaseman kotelointi estää lasersäteen pääsyn laitteen ulkopuolelle.

Laitteen turvallisuusluokka on määritetty standardin EN 60825 mukaisesti.

VAROITUS !

Laitteen käyttäminen muulla kuin käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle lasersäteilylle.

WARNING !

Om apparaten används på annat sätt än i bruksanvisning specificerats, kan användaren utsättas för laserstrålning, som överskrider gränsen för laserklass 1.

Huolto

HP SureStore Optical 160ex, 320ex, 400ex levymuistiasemien sisällä ei ole käyttäjän huollettavissa olevia kohteita. Laitteen saa avata ja huoltaa ainoastaan sen huoltamiseen koulutettu henkilö. Levymuistiaseman sisälle asennettujen luku-/kirjoitusyksiköiden suojakotelo ei tule avata huoltotoimenpiteiden yhteydessä.

VARO !

Mikäli luku-/kirjoitusyksikön suojakotelo avataan ja suojalukitus ohitetaan, olet alttiina lasersäteilylle laitteen ollessa toiminnassa. Älä katso säteeseen.

WARNING !

Om skyddshöljet av den optiska drivmodulen öppnas och spärren urkopplas då apparaten är i funktion, utsättas användaren för laserstrålning. Betrakta ej strålen.

Tiedot luku-/kirjoitusyksikössä käytettävän laseriodin säteilyominaisuuksista:

Aallonpituus 680 nm

Teho 60 mW

Turvallisuusluokka 3B

English Translation of Finland Regulatory Information

LASER SAFETY SUMMARY

LASER SAFETY

CLASS 1 LASER PRODUCT (The same in Swedish.)

HP SureStore Optical 160ex, 320ex and 400ex jukeboxes are for user safe class 1 laser products. In normal use the enclosure of the optical drives prevents the laser beam from escaping outside of the product.

The jukebox was type approved in Finland for laser safety by the National Board of Labour Protection. The safety class of the products was defined according to the resolution No 472/1985 of the Council of State and the standard EN 60825.

WARNING !

The use of the product otherwise than specified in the user's manual may expose the user to laser radiation exceeding safety class 1.

(The same warning in Swedish.)

SERVICE

There are no user serviceable parts inside the jukebox. The jukebox products can be serviced only by qualified service personnel. The optical drive mechanism(s) installed inside the library system shall not be opened or disassembled during service.

WARNING !

If the enclosure of the optical drive mechanism is opened and the safety interlock disabled, you may be exposed to the laser radiation when the drive is operating. Avoid exposure to the beam.

(The same warning in Swedish.)

The information about the radiation characteristics of the laser diode used in the optical drive mechanism:

Wavelength	680 nm
Power	60 mW
Class	3B laser

Japanese VCCI Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

This equipment is in the Class A category information technology equipment based on the rules of Voluntary Control Council For Interference by Information Technology Equipment (VCCI). When used in a residential area, radio interference may be caused. In this case, user may be required to take appropriate corrective actions.

Index

C

changing the administration password 3-13
changing the SCSI IDs 3-16
characteristics
 jukebox 1-4
 optical drive 1-3
configuration module 6-9
configurations
 listing of 3-20
 setting 3-19
connecting
 with other devices on the bus 2-9
connecting power 2-10
connecting the jukebox
 only peripheral 2-7
connecting the SCSI cables 2-6
control panel 2-3
 16-character display 3-5
 activity light 3-5
 selection buttons 3-5
 swivel feature 3-5
controller PCA 6-5
controls
 LOAD button 3-7
conventions
 typographical iii

D

declaration of conformity A-5
disks
 ejecting 3-11
 loading 3-10
display menu tree 3-6
display messages
 ADMIN * 3-8
 CONFIG * 3-8
 INFO * 3-8
 ONLINE REPAIR * 3-8
 READY 3-8
 SCSI IDs * 3-8
 second level 3-8

TEST * 3-8
 top level 3-8
drives 6-20

E

ejecting a disk 3-11
entering the administration password 3-12
environmental specifications 1-5
error verification and recovery 4-12

G

German sound emission A-6

I

installation error recovery 4-5
installation responsibilities 1-10
internal tests
 descriptions 4-39
 listing of 4-39
 running 4-39
 used by service 4-39
interposer PCA 6-7

J

Japanese VCCI A-9
jukebox
 controller PCA 6-5
 interposer PCA 6-7
 picker 6-19
 power supplies 6-10
 robotic movements 6-3
 SCSI interface PCA 6-11
jukebox logs 3-22

L

left access panel 2-5
loading a disk 3-10
logs 3-22
 listing of 3-22

M

mailslot 2-3, 3-5
menu tree 3-6
micro-move descriptions 4-27
micro-move error codes 4-23
micro-move IDs 4-27
moving the jukebox 2-18

O

operation error recovery 4-5
optical drives 6-20

P

parts
 exchange 5-51
 non-exchange 5-51
password
 changing 3-13
 entering 3-12
picker 6-19
power
 connecting 2-10
power receptacle 2-5
power supplies 6-10
power switch 2-3, 3-5
precautions
 disassembling the optical drive 5-3
 ESD 5-3
product certifications 1-8

R

regulations
 CDRH A-3
 finnish A-7
 United Kingdom
 telecommunications A-4
regulatory compliance A-1
related documents 1-11
reliability 1-8
removing panels 5-5
replaceable parts 5-51

Index

- replacing
 - control panel assembly 5-11
 - controller PCA 5-39
 - encoder strip 5-33
 - interface PCA 5-41
 - interposer PCA 5-21
 - mailslot assembly 5-9
 - optical drive
 - offline 5-12
 - online 5-16
 - picker 5-22
 - power supply 5-8
 - SCSI cable 5-44
 - translate frame 5-27
 - vertical motion gear box 5-35
 - vertical motion motor 5-34
 - required tools 5-3
 - requirements
 - clearance 1-8
 - location 1-9
 - power 1-7
 - retrieving logs 3-22
 - RFI adjustments 5-45
 - right service access panel 2-3
- S**
- safety regulations compliance A-1
 - SCSI
 - configuring this jukebox 6-14
 - SCSI bus
 - active bus indicator 2-5
 - interface selection switch 2-5
 - ports 2-5
 - SCSI cables
 - connecting 2-6
 - maximum length 2-6
 - SCSI IDs
 - changing 3-16
 - conflict 3-17
 - must be one digit apart 3-17
 - setting LUN mode 3-14
 - setting 3-14
 - viewing 3-14
 - when in LUN mode 3-17
 - SCSI interface PCA 6-11
 - selection buttons
 - using 3-7
 - setting an operating configuration 3-19
 - setting SCSI IDs 3-14
 - setting the LUN mode 3-14
 - shipping the jukebox 2-18
- T**
- tests
 - internal 4-39
 - tools needed for upgrading firmware 5-47
 - tools required 5-3
 - troubleshooting
 - hardware errors 4-12
 - listing of procedures 4-5
 - table 4-5
 - using the control panel 4-3
 - type styles in this book iii
- U**
- upgrading firmware 5-47
- V**
- viewing the SCSI IDs 3-14
- W**
- write verify 2-11
 - changing 2-11